

CARRYALL 300 ELECTRIC Operators Manual



APPLICABLE TO CARRYALL 300 ERIC ELECTRIC VEHICLES WITH SERIAL PREFIX OF MF



Copyright © 2018 Club Car, LLC This manual effective July 15, 2018

VEHICLE OWNERSHIP

Congratulations! The Club Car brand is widely recognized as the industry leader in vehicle efficiency and long-lasting value. Read, understand, and obey the technical content in this manual to protect your investment and provide years of reliable vehicle operation.

Read, understand, and obey all instructions and safety precautions in this manual to prevent the risk of personal injury or property damage.

Club Car recommends owners that rent or loan vehicles make sure operators read this manual before vehicle operation.

Club Car recommends owners register their vehicles immediately after purchase. The previous owner must include this manual with the vehicle when sold to a new owner. Registration of the vehicle will make sure Club Car is able to communicate necessary information directly to owners. Send your name, address, and serial number of the vehicle to:

> Club Car, LLC Attention: Vehicle Registration P.O. Box 204658 Augusta, Georgia 30917-4658 United States Of America

CALIFORNIA PROPOSITION 65

Г

	OPERATING, SERVICING AND MAINTAINING A
🗥 WARNING	PASSENGER VEHICLE OR OFF-ROAD VEHICLE
	CAN EXPOSE YOU TO CHEMICALS INCLUDING
	ENGINE EXHAUST, CARBON MONOXIDE,
	PHTHALATES, AND LEAD, WHICH ARE KNOW
	TO THE STATE OF CALIFORNIA TO CAUSE
	CANCER AND BIRTH DEFECTS OR OTHER
	REPRODUCTIVE HARM. TO MINIMIZE
	EXPOSURE, AVOID BREATHING EXHAUST, DO
	NOT IDLE THE ENGINE EXCEPT AS NECESSARY,
	SERVICE YOUR VEHICLE IN A WELL-
	VENTILATED AREA AND WEAR GLOVES OR
	WASH YOUR HANDS FREQUENTLY WHEN
	SERVICING YOUR VEHICLE. FOR MORE
	INFORMATION GO TO WWW.P65WARNINGS.
	CA.GOV/PASSENGER-VEHICLE.
	·

APPROVED DEALERS AND DISTRIBUTORS

Club Car's customer support system offers fast and courteous service. Speak with your dealer or distributor for:

Page i



- Accessories
- Publications
- Replacement Parts

- Technical Advice
- Warranty Work



To find your nearest dealer or distributor:

- Visit www.clubcardealer.com
- Scan the dealer locator Quick Response (QR) code

COMPANY CONTACT INFORMATION

Send written correspondence to:

Club Car, LLC Attention: Marketing Services P.O. Box 204658 Augusta, Georgia 30917-4658 United States Of America

CUSTOMER SATISFACTION SURVEY

Let your voice be heard!

Your feedback will help improve our publications. You can access the survey through any internet-connected device with a web browser. The survey is available in many different languages.

Scan the Quick Response (QR) code or type the web address http://bit.ly/1w9uFMh to complete the survey.





VEHICLE MODEL AND SERIAL NUMBER

The vehicle serial number is located on a bar code decal installed near the accelerator.

- 1. A two-letter code that identifies the vehicle model.
- 2. A four-digit code that identifies the model year and production week the vehicle was assembled.
- 3. A unique six-digit number given to each vehicle built within a specified model year.



LIABILITY AND VEHICLE DESIGN CHANGES

Club Car is not liable for errors in this manual or for incidental or consequential damages that result from the use of the material in this manual.

Club Car reserves the right to make design changes to vehicles without obligation to make these changes on units previously sold.

This manual is the original instructions provided by the manufacturer if in English. This manual is a translation of the original instructions if in any language other than English.

VEHICLE MODIFICATIONS

🛕 DANGER 🛛

MODIFICATIONS OR CHANGES TO THE VEHICLE THAT AFFECT THE OCCUPANT RETENTION, ELECTRICAL SYSTEM, STABILITY OR HANDLING OF THE VEHICLE, OR INCREASES THE MAXIMUM VEHICLE SPEED CAN CAUSE SERIOUS PERSONAL INJURY OR DEATH.

NOTICE

MODIFICATIONS TO THE VEHICLE MUST NOT COMPROMISE COMPLIANCE WITH STATE OR FEDERAL REGULATIONS.

Do not install non-Club Car approved accessories or change the vehicle function to increased speed or power. Modifications or installation of non-Club Car approved accessories could cause a substantial safety hazard and increase the risk of bodily injury or property damage.

The warranty on your vehicle will be canceled if non-Club Car approved equipment and/or modifications have been added to the vehicle that increase speed or power.

The performance characteristics of the vehicle may change because of the addition of some accessories, including (but not limited to) lift kits, tires, or large racks. Use only Club Car approved accessories. Know the function of the accessories and their effects on the vehicle.

VEHICLE WARRANTY

Warranty information is located in the warranty section of this manual. No other expressed or implied warranties are contained herein.

Your dealer or distributor examined the vehicle before it was delivered to you. The dealer or distributor will also supply you a copy of the completed vehicle warranty registration form.

Page iii



GOVERNMENTAL AND INDUSTRY STANDARDS

U.S.A. FEDERAL VEHICLE SAFETY STANDARDS

The configuration of this vehicle does not comply with United States Of America Federal Motor Vehicle Safety Standards (FMVSS) for automobiles and FMVSS 500 for low-speed vehicles as it existed on the date the vehicle was shipped from the Club Car manufacturing facility. This four-wheel general-purpose vehicle is intended to transport people and cargo on improved or groomed surfaces.

EUROPEAN UNION VIBRATION AND NOISE PREN 15997

European Union specification prEN 15997 was used to measure the vibration and noise levels of the vehicle. The vibration and noise values are recorded in the vehicle specification section of this manual.

PUBLICATION COPYRIGHT

This manual contains proprietary information that is protected by copyright. All rights are reserved. Express written consent of Club Car, LLC is necessary to photocopy, replicate, or translate this manual. The information contained in this publication is subject to change without notice.



CONTENTS

	I
NOTICES	
SECTION 1 - SAFETY INFORMATION	9
General Safety Information	
Practice Safety	
Safety Signal Words	
Safety Committee	
Vehicle Safety Information	
Vehicle Safety And Compliance Decals	
Vehicle Safety Features Battery Charging Interlock	
Multi-Purpose Buzzer	
Regenerative Braking	
Walk-Away Braking	
Falling Object Protection System	
Battery Safety Information	
Battery International Safety Symbols	
Lead-Acid Battery Recycling	
SECTION 2 - INDICATORS, GAUGES, AND DISPLAYS	19
Indicator, Gauge, And Display Locations	20
Battery Condition Indicator	
Charge Indicator Light	
SECTION 3 – VEHICLE CONTROLS	23
Vehicle Controls Locator	
Accelerator Pedal	
Accelerator Pedal Brake Pedal	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn. Key Switch. Park Brake	24 25 25 25 25 25 25 26 26 26 26 26 27
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch	24 25 25 25 25 25 25 26 26 26 26 26 27 27 27
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever	24 25 25 25 25 25 25 26 26 26 26 26 27 27 27 27 28
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch Modular Cab Controls	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch Modular Cab Controls Defrost And Heater Switch	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch Modular Cab Controls Defrost And Heater Switch Dome Light Switch	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch Modular Cab Controls Defrost And Heater Switch Dome Light Switch Lower Dash Fan Switch	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch Modular Cab Controls Defrost And Heater Switch Dome Light Switch Lower Dash Fan Switch Upper Cab Fan Switch	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch Modular Cab Controls Defrost And Heater Switch Dome Light Switch Lower Dash Fan Switch Strobe Light Switch	
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch Modular Cab Controls Defrost And Heater Switch Dome Light Switch Lower Dash Fan Switch Upper Cab Fan Switch	24 25 25 25 26 26 26 26 26 27 27 27 27 27 28 28 28 28 28 28 28 29 29 29 29 29 29 29 29 29 29 29 30
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch Defrost And Heater Switch Defrost And Heater Switch Lower Dash Fan Switch Upper Cab Fan Switch Upper Cab Fan Switch Windshield Washer Switch SECTION 4 – VEHICLE FEATURES	24 25 25 25 26 26 26 26 26 27 27 27 27 28 28 28 28 28 28 28 29 29 29 29 29 29 29 29 30 30
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch Modular Cab Controls Defrost And Heater Switch Dome Light Switch Lower Dash Fan Switch Strobe Light Switch Upper Cab Fan Switch Windshield Washer Switch Strobe Light Switch Upper Cab Fan Switch Windshield Washer Switch Vehicle Features Description	24 25 25 25 25 26 26 26 26 26 27 27 27 27 27 27 28 28 28 28 28 29 29 29 29 29 29 30 31
Accelerator Pedal Brake Pedal Electric Bed Lift Switch Forward / Neutral / Reverse Control Hazard Light Switch Headlight Switch Horn Key Switch Park Brake Run/Tow Switch Turn Signal Lever Windshield Wiper Switch Defrost And Heater Switch Defrost And Heater Switch Lower Dash Fan Switch Upper Cab Fan Switch Upper Cab Fan Switch Windshield Washer Switch SECTION 4 – VEHICLE FEATURES	24 25 25 25 26 26 26 26 26 26 27 27 27 27 27 28 28 28 28 28 28 29 29 29 29 29 29 30 31



Capacity	
Operation	
Modular Cab	
Tilt Cargo Bed	
Description	33
Operation	33
12-Volt Power Receptacle VersAttach System	
versatlach system	35
SECTION 5 – BATTERY CHARGER	37
Introduction	38
ERIC IC650 Specifications	
Manufacturer Information	
Dimension And Weight	
Operational Temperature	39
AC Input	
DC Output	40
Governmental And Industry Certifications	
European Conformity	40
Federal Communications Commission	
International Protection Marking	40
Underwriters Laboratories And Canadian Standards Association	
Features	
AC Electrical Cord And Plug	
Status Indicator Lights Battery Charging Interlock	41
External Battery Charger Mounting	45
How To Make Strain Relief And Drip Loop	
Inspection And Maintenance	
Electrical Cords	
Electrical Plugs And Receptacles	40
Electrical Plugs And Receptacles Clean The Electrical Plugs And Receptacles	45
Electrical Plugs And Receptacles Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle	45
Clean The Electrical Plugs And Receptacles	45 45
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle	45 45 45
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS	45 45 45 47
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions	45 45 45 47 48
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions Performance	45 45 45 45 48 48
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions Performance Tires	45 45 45 45 45 48 48 48
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions Performance Tires Electric Motor	45 45 45 45 45 45 48 48 48 48 48
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS. Dimensions Performance Tires Electric Motor Batteries	45 45 45 45 45 45 48 48 48 48 48 48
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions Performance Tires Electric Motor Batteries Noise And Vibration	45 45 45 45 45 45 45 48 48 48 48 49 49 49
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions Performance Tires Electric Motor Batteries Noise And Vibration Transaxle	45 45 45 45 45 45 45 48 48 48 48 48 49 49 49 49
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions Performance Tires Electric Motor Batteries Noise And Vibration	45 45 45 45 45 45 45 48 48 48 48 48 49 49 49 49
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions Performance Tires Electric Motor Batteries Noise And Vibration Transaxle	45 45 45 45 45 45 45 45 48 48 48 48 48 48 49 49 49 49 49
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions Performance Tires Electric Motor Batteries Noise And Vibration Transaxle Vehicle Weights And Load Capacities SECTION 7 – VEHICLE OPERATION	45 45 45 45 48 48 48 48 48 49 49 49 49 49 49 49 49
Clean The Electrical Plug's And Receptacles	45 45 45 45 48 48 48 48 48 49 49 49 49 49 49 49 49 49 45 53
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions Performance Tires Electric Motor Batteries Noise And Vibration Transaxle Vehicle Weights And Load Capacities SECTION 7 – VEHICLE OPERATION Daily Pre-Operational Safety And Performance Checks Overview	45 45 45 45 48 48 48 48 48 49 49 49 49 49 49 49 49 49 53 53
Clean The Electrical Plugs And Receptacles	45 45 45 45 45 48 48 48 48 49 49 49 49 49 49 49 49 49 49 53 53 54
Clean The Electrical Plug's And Receptacles	45 45 45 45 45 48 48 48 48 49 49 49 49 49 49 49 49 49 53 53 54 54
Clean The Electrical Plugs And Receptacles	45 45 45 45 45 47 48 48 48 48 48 49 49 49 49 49 49 49 49 49 49 53 53 54 54 56
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 – VEHICLE SPECIFICATIONS Dimensions Performance Tires Electric Motor Batteries Noise And Vibration Transaxle. Vehicle Weights And Load Capacities SECTION 7 – VEHICLE OPERATION Daily Pre-Operational Safety And Performance Checks Overview Daily Pre-Operational Safety Checklist Vehicle Performance Inspection Vehicle Movement Overview	45 45 45 45 45 47 48 48 48 48 49 49 49 49 49 49 49 49 49 49 53 53 54 54 56 56
Clean The Electrical Plugs And Receptacles	45 45 45 45 45 47 48 48 48 48 49 49 49 49 49 49 49 49 49 49 53 53 54 56 56 56
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 - VEHICLE SPECIFICATIONS Dimensions Performance Tires Electric Motor Batteries Noise And Vibration Transaxle Vehicle Weights And Load Capacities SECTION 7 - VEHICLE OPERATION Daily Pre-Operational Safety And Performance Checks. Overview Daily Pre-Operational Safety Checklist Vehicle Performance Inspection Vehicle Movement Overview Dotor Start Turn Off Motor Forward Movement	45 45 45 45 45 45 47 48 48 48 48 49 49 49 49 49 49 49 49 49 49 53 53 54 56 56 56 57
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 - VEHICLE SPECIFICATIONS Dimensions Performance. Tires Electric Motor Batteries. Noise And Vibration Transaxle. Vehicle Weights And Load Capacities. SECTION 7 - VEHICLE OPERATION Daily Pre-Operational Safety And Performance Checks. Overview. Daily Pre-Operational Safety Checklist Vehicle Performance Inspection Vehicle Movement Overview. Motor Start Turn Off Motor Forward Movement	45 45 45 45 45 45 45 48 48 48 48 48 48 49 49 49 49 49 49 49 49 49 49 49 49 53 54 56 56 57 57 57
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 - VEHICLE SPECIFICATIONS Dimensions Performance Tires Electric Motor Batteries Noise And Vibration Transaxle. Vehicle Weights And Load Capacities SECTION 7 - VEHICLE OPERATION Daily Pre-Operational Safety And Performance Checks. Overview Daily Pre-Operational Safety Checklist Vehicle Performance Inspection Vehicle Performance Inspection Vehicle Performance Inspection Vehicle Movement Overview Motor Start Turn Off Motor Forward Movement Reverse Movement Slow Or Stop The Vehicle	45 45 45 45 45 45 45 48 48 48 48 48 48 49 49 49 49 49 49 49 49 49 49 49 49 53 53 54 56 56 57 57 58
Clean The Electrical Plugs And Receptacles Battery Charger USB Receptacle Clean The USB Receptacle SECTION 6 - VEHICLE SPECIFICATIONS Dimensions Performance. Tires Electric Motor Batteries. Noise And Vibration Transaxle. Vehicle Weights And Load Capacities. SECTION 7 - VEHICLE OPERATION Daily Pre-Operational Safety And Performance Checks. Overview. Daily Pre-Operational Safety Checklist Vehicle Performance Inspection Vehicle Movement Overview. Motor Start Turn Off Motor Forward Movement	45 45 45 45 45 45 48 48 48 48 48 49 49 49 49 49 49 49 49 49 49 49 49 53 54 56 56 57 57 58 58 58


Unpaved Surfaces	. 58
Uphill Slope	. 58
Side Hill Slope	
Downhill Slope	
Over Obstacles	
Below Obstacles	
Night Time	
Through Water	
With Cargo	. 62
SECTION 8 - VEHICLE MAINTENANCE	.65
Disable The Vehicle	67
Vehicle Cleaning	
Windshield	
Vehicle Exterior	
Vehicle Interior	
Maintenance Schedule	
Overview	
Service Schedule	
Maintenance Tasks	
Lift The Vehicle	
Lower The Vehicle	
Tire Pressure Measurement	
Wheel Assembly	. 73
SECTION 9 – BATTERY MAINTENANCE	75
	70
Battery Cleaning	76
Battery Charging	76
Charging With External Charger	70
Charging With Onboard Charger	/ð
Battery Electrical Connection Disconnect	
Connect	
Battery Hold-Down	
Add Water To A Battery Without Single Point Watering System	. 00
Deionizer	
Add Water To Batteries With Single Point Watering System	. 02
Watering Intervals	82
Water Quality	
Overview	82
Preferred Sources	
Alternate Sources	
Water Impurity	
SECTION 10 - TRANSPORT AND TOW	85
Prepare The Vehicle To Be Towed	86
Tow With The Vehicle	86
Vehicle Transport Preparation	86
Vehicle Transport Recovery	. 87
SECTION 11 - EXTENDED STORAGE	89
Extended Storage Preparation	90
Return To Service From Extended Storage	. 91
SECTION 12 - WARRANTIES	
Limited Warranty Warranty	



Varranty Timeframe	94
xclusions	
oiding Of Warranty	
Sole Remedy	
Disclaimer	96
lo Conseguential Damages	96
low To Make A Warranty Claim	97







SAFETY INFORMATION



PRACTICE SAFETY

1



Signal words (DANGER, WARNING, CAUTION, and NOTICE) and safety messages are in this manual and on safety decals. Read, understand, and obey all instructions, safety precautions, and safety decals before vehicle operations.

Replace missing, damaged, or unreadable safety decals immediately to prevent possible property damage, personal injury, or death. Purchase replacement safety decals from your dealer or distributor.

Know and understand all laws and regulations for vehicle operation in your area.

Speak with your dealer or distributor if you have questions about material contained in this manual or the vehicle.

SAFETY SIGNAL WORDS

Signal words (DANGER, WARNING, CAUTION, and NOTICE) and safety messages are in this manual and on safety decals. Read, understand, and obey all instructions, safety precautions, and safety decals before vehicle operations.

Safety messages are necessary and must be obeyed.



The safety alert symbol is used to alert you to possible personal injury hazards. Obey all safety messages that follow this symbol to prevent possible injury or death.

SAFETY SIGNAL WORD	SIGNIFICANCE
A DANGER	A DANGER identifies a hazardous situation which will result in death or serious injury.
	A WARNING identifies a hazardous situation which could result in death or serious injury.

Page 10

SAFETY SIGNAL WORD	SIGNIFICANCE
	A CAUTION identifies a hazardous situation which could result in minor or moderate injury.
NOTICE	A NOTICE identifies a hazardous situation which could result in property damage.

SAFETY COMMITTEE

If the vehicle is rented or part of a fleet, Club Car recommends setting up a safety committee. The primary concern of the safety committee is safe vehicle operation.

Safety committee objectives include:

- Approve vehicle operation areas.
- Identify all hazards.
- Identify who is approved to operate the vehicle.
- Keep the vehicles in a safe and serviceable condition.
- Supply instructions on safe vehicle operation.
- Visually show all hazards.

VEHICLE SAFETY INFORMATION

🛕 DANGER

FAILURE TO OBEY INSTRUCTIONS IN THIS MANUAL CAN CAUSE PROPERTY DAMAGE, SERIOUS PERSONAL INJURY, OR DEATH. BEFORE YOU OPERATE THE VEHICLE OR DO THE SERVICING OF THE VEHICLE, READ AND FULLY UNDERSTAND THE OWNER'S MANUAL.

CLUB CAR VEHICLES ARE NOT RATED FOR OPERATION IN EXPLOSIVE AREAS. THE VEHICLE OR BATTERY CHARGER CAN CAUSE FLAMMABLE MATERIAL AND FUME IGNITION. DO NOT OPERATE THE VEHICLE OR BATTERY CHARGER NEAR FLAMMABLE MATERIALS AND FUMES.

THE VEHICLE DOES NOT GIVE PROTECTION FROM LIGHTNING, FLYING OBJECTS, OR OTHER STORM RELATED HAZARDS. DO NOT OPERATE THE VEHICLE IN STORMS. STOP THE VEHICLE. GET OUT OF THE VEHICLE IMMEDIATELY AND FIND A SHELTER IN ACCORDANCE WITH APPLICABLE SAFETY GUIDELINES FOR YOUR LOCATION IF IN A STORM.

UNINTENDED VEHICLE OPERATION CAN CAUSE SERIOUS PERSONAL INJURY OR DEATH. MAKE SURE THAT CHILDREN ARE ALWAYS SUPERVISED IN AND AROUND THE VEHICLE.

DO NOT OPERATE THE VEHICLE UNDER THE INFLUENCE OF ALCOHOL, DRUGS, MEDICATIONS, OR WHILE DISTRACTED.






	ELECTRICAL SHORTS CAN CAUSE A FIRE OR ELECTRICAL SHOCK. PREVENT CONTACT BETWEEN POSITIVE VOLTAGE AND THE GROUND CIRCUIT. USE INSULATED TOOLS.
	TO HELP PREVENT BEING HIT, DO NOT STAND IN FRONT OF OR BEHIND THE VEHICLE.
	ONLY TWO PERSONS PER BENCH SEAT. ONLY RIDE ON THE BENCH SEAT. DO NOT LET PEOPLE RIDE ON ANY PART OF THE VEHICLE THAT IS NOT EQUIPPED WITH A SEAT. DO NOT LET A PASSENGER HOLD A CHILD IN HIS OR HER LAP WHILE THE VEHICLE MOVES.
	ONLY TRAINED TECHNICIANS SHOULD SERVICE OR REPAIR THE VEHICLE. ANYONE DOING EVEN SIMPLE REPAIRS OR SERVICE SHOULD HAVE KNOWLEDGE AND EXPERIENCE IN ELECTRICAL AND MECHANICAL REPAIR. THE APPROPRIATE INSTRUCTIONS MUST BE USED WHEN PERFORMING MAINTENANCE, SERVICE, OR ACCESSORY INSTALLATION.
A CAUTION	ACCESSORIES ATTACHED TO THE BED SIDES CAN ADD WIDTH TO THE VEHICLE, HIT NEARBY PERSONS OR OBJECTS, AND CAUSE PERSONAL INJURY AND PROPERTY DAMAGE. USE CAUTION WHEN OPERATING THE VEHICLE WITH ACCESSORIES ATTACHED TO THE BED SIDES.
VEHICLE SAFETY AND CO	MPLIANCE DECALS

WARNING


MAKE SURE ALL OF THE SAFETY AND OPERATION DECALS ARE IN THE CORRECT LOCATION ON THE VEHICLE. REPLACE THE SAFETY AND OPERATION DECALS THAT ARE MISSING OR DAMAGED.

Understand and obey all safety decals. The instructions on these safety decals must be followed in order to prevent the risk of dangerous personal injury or property damage.

Use a soft moist cloth to clean the decals. Do not use solvents, gasoline, or other chemicals to clean the decals.









ROLLOVERS CAN CAUSE SERIOUS INJURY OR DEATH Place cargo forward in the cargo bed and distribute evenly side to side. Secure load. On uneven or steep terrain, reduce speed and load. Avoid stopping on or backing down steep hills.



NOTICE VEHICLE LOADING

Read and understand the Operators Manual and safety decals. 300 lb (136 kg) maximum cargo load. Includes cargo, bed load, optional equipment, and trailer tounge weight. 800 lb (363 kg) vehicle rated capacity on a level surface. Includes occupants and cargo load. 800 lb (363 kg) vehicle combination rated capacity. Includes vehicle rated capacity and gross trailer weight.

13. Vehicle Load Warning Decal

<u> </u>	ARNING
UNINTENDED MOVEMENT, ROLLOVER, OR FALL	ING OUT CAN CAUSE SERIOUS INJURY OR DEATH.
 Vehicle to be operated by licensed and authorized persons only. Use in authorized areas only. Do not operate on public roads. One (1) person per bucket seat maximum. Two (2) persons per bench seat maximum. Operate from driver's seat only. Do not start vehicle until all occupants are fully seated. Drive slowly in turns and straight up and down slopes. 	 Remain fully seated while moving. Hold on and keep entire body inside vehicle while moving. Never attempt jumps and avoid extreme braking in reverse. Do not leave children unattended in vehicle at any time. Children requiring a child safety seat must not ride in vehicle. Never operate under the influence of alcohol or drugs.
14. Occupant	Warning Decal

VEHICLE SAFETY FEATURES

BATTERY CHARGING INTERLOCK

<u>External Battery Charger</u>: The battery charging interlock is a safety feature that prevents possible damage to the battery charger and vehicle. The battery charging interlock will automatically engage when the DC cord is connected to the vehicle. The vehicle will not operate when the DC cord is connected.

Note: The AC cord does not have to be connected for the battery charging interlock to operate.

<u>Onboard Battery Charger</u>: The battery charging interlock is a safety feature that prevents possible damage to the battery charger and vehicle. The battery charging interlock will automatically engage when the AC cord is connected to a power source. The vehicle will not operate when the AC cord is connected.

MULTI-PURPOSE BUZZER

The vehicle comes equipped with a multi-purpose buzzer. The multi-purpose buzzer makes an audible tone when:

- The Forward / Neutral / Reverse control (FNR) is set to R.
- The walk-away braking engages for longer than two seconds.
- The regenerative braking performance decreases because the batteries are fully charged.
- The batteries start to charge.

REGENERATIVE BRAKING

A CAUTION

WHEN THE BATTERIES ARE FULLY CHARGED, A WARNING BUZZER WILL OPERATE DURING REGENERATIVE BRAKING TO TELL THE DRIVER THAT REGENERATIVE BRAKING PERFORMANCE WILL DECREASE. USE THE BRAKE PEDAL TO CONTROL THE VEHICLE SPEED.





Regenerative braking helps maintain the downhill speed of the vehicle in relation to the accelerator pedal position.

Regenerative braking performance decreases when the batteries are fully charged.

PEDAL POSITION	CONDITION
Fully Pushed	Regenerative braking holds the vehicle at the programmed top speed.
Between Fully Pushed And Released	Regenerative braking holds the vehicle at a percentage of the programmed top speed in relation to the pedal position.
Fully Released	 Regenerative braking will do one of the two based on the controller settings: Factory Default - Stop the vehicle slowly. Optional - Let the vehicle coast freely. <i>Note:</i> The regenerative braking functions are controlled by the controller settings. Speak with your dealer or distributor for more information.

WALK-AWAY BRAKING

WALK AWAY BRAKING WILL NOT LIMIT VEHICLE SPEED TO 3 MPH (4.8 KM/H) ON STEEP SLOPES. DO NOT OPERATE THE VEHICLE ON SLOPES THAT ARE MORE THAN A 20% INCLINE.

Walk-away braking is a safety function that limits the roll-away speed of a vehicle when the park brake is disengaged. The multi-purpose buzzer will make an audible tone when the walk-away braking safety device engages for more than two seconds.

FALLING OBJECT PROTECTION SYSTEM

The Falling Object Protection System (FOPS) protects the vehicle occupants from falling debris.

The FOPS is not a Roll-Over Protective Structure (ROPS).

BATTERY SAFETY INFORMATION

BATTERY ACID CAN CAUSE SERIOUS BURNS. PREVENT CONTACT \Lambda DANGER WITH SKIN, EYES, AND CLOTHING. WEAR A FULL FACE SHIELD AND RUBBER GLOVES WHEN SERVICING A BATTERY. ANTIDOTES: EXTERNAL: FLUSH WITH WATER. CALL A PHYSICIAN IMMEDIATELY. INTERNAL: DRINK LARGE **QUANTITIES OF MILK OR WATER FOLLOWED WITH MILK OF** MAGNESIA OR VEGETABLE OIL. CALL A PHYSICIAN **IMMEDIATELY. EYES: FLUSH WITH WATER FOR 15 MINUTES.** CALL A PHYSICIAN IMMEDIATELY. FROZEN BATTERY ACID CAN CAUSE DAMAGE INCLUDING LEAKS / WARNING AND EXPLOSIONS. IF THE BATTERY ACID FREEZES, REPLACE THE **BATTERY BEFORE CHARGING OR USE. BATTERIES IN A LOW** STATE OF CHARGE WILL FREEZE AT LOW TEMPERATURES. KEEP THE BATTERIES IN A HIGH STATE OF CHARGE.



FLOODED BATTERIES CAN CAUSE DAMAGE INCLUDING LEAKS AND EXPLOSION. IF A BATTERY IS SUBMERGED, REPLACE THE BATTERY BEFORE CHARGING OR USE.

LOOSE BATTERY WIRES CAN CAUSE A FIRE. MAKE SURE THAT ALL BATTERY WIRES AND TERMINALS ARE CLEAN AND TIGHTENED CORRECTLY.

BATTERY WIRES WITH DAMAGE OR CORROSION CAN BECOME TOO HOT AND CAUSE A FIRE, PROPERTY DAMAGE, OR PERSONAL INJURY. REPLACE BATTERY WIRES WITH DAMAGE OR CORROSION. CLEAN CORROSION FROM THE BATTERY TERMINALS.

BATTERY INTERNATIONAL SAFETY SYMBOLS

Understand and obey the international safety symbols on the vehicle battery before you use, repair, or service the vehicle.

SYMBOL	SIGNIFICANCE
	Shield eyes
	Read and obey operation and maintenance instructions
	Do not smoke, No open flames, No sparks
	Keep away from children
	Battery acid hazard
	Explosive gas hazard






LEAD-ACID BATTERY RECYCLING

LEAD-ACID BATTERIES CONTAIN DANGEROUS MATERIALS THAT CAN CONTAMINATE THE WATER AND SOIL, CAUSE ENVIRONMENTAL DAMAGE, AND CAUSE PERSONAL INJURY. SPEAK WITH YOUR DEALER OR DISTRIBUTOR FOR INFORMATION ON HOW TO DISCARD A BATTERY CORRECTLY.

Lead-acid batteries and other components which have the Waste Electrical and Electronic Equipment (WEEE) symbol printed on them must be collected and recycled separately from other waste. Do not discard lead-acid batteries as municipal waste.

Speak with your dealer or distributor on how to correctly recycle lead-acid batteries.








INDICATORS, GAUGES, AND DISPLAYS



INDICATOR, GAUGE, AND DISPLAY LOCATIONS



BATTERY CONDITION INDICATOR




The battery condition indicator gives a visual indication of the batteries state of charge (SOC). The battery condition indicator has a 10-bar LED display.

CHARGE INDICATOR LIGHT

NOTICE

WHEN THE CHARGE INDICATOR LIGHT IS ON, CHARGE BATTERIES AS QUICKLY AS POSSIBLE.



The charge indicator lamp gives a visual indication when:

- The battery state of charge (SOC) is less than 20%. Charge the batteries as quickly as possible.
- The batteries start to charge.

Note: The multi-purpose buzzer will operate three times.



STATUS	CONDITION
OFF	Battery SOC is more than 20%.
ON (CONSTANT)	Battery SOC is less than 20% but more than 10%.
ON (FLASH ON AND OFF)	Battery SOC is less than 10%.
ON (FLASH ON AND OFF THREE TIMES)	The batteries charging has started.




(Page intentionally left blank.)



VEHICLE CONTROLS



VEHICLE CONTROLS LOCATOR



1. Accelerator Pedal	2. Brake Pedal
3. Park Brake	4. Key Switch
5. Forward / Neutral / Reverse Control (FNR)	6. Headlight Switch
7. Run/Tow Switch	8. Electric Bed Lift Switch (Optional Equipment)
9. Turn Signal Lever (Optional Equipment)	10. Horn (Optional Equipment)
11. Windshield Wiper Switch (Optional Equipment)	12. Hazard Lights Switch (Optional Equipment)

ACCELERATOR PEDAL




The accelerator pedal is used to increase and maintain the speed of the vehicle.

BRAKE PEDAL



The brake pedal is used to decrease speed or stop the vehicle.

ELECTRIC BED LIFT SWITCH




The electric bed lift switch controls the movement of the cargo bed.

POSITION	FUNCTION
Тор	Lift
Bottom	Lower

FORWARD / NEUTRAL / REVERSE CONTROL

🗥 WARNING

FAILURE TO STOP THE VEHICLE BEFORE SHIFTING THE FORWARD / NEUTRAL / REVERSE CONTROL (FNR) CAN CAUSE PERSONAL INJURY AND VEHICLE DAMAGE. STOP THE VEHICLE BEFORE SHIFTING THE FORWARD / NEUTRAL / REVERSE CONTROL (FNR).




The Forward / Neutral / Reverse control (FNR) sets the direction of vehicle movement.

Stop the vehicle to change the FNR position.

POSITION	FUNCTION
F	Forward
N (Center)	Neutral
R	Reverse

HAZARD LIGHT SWITCH



The hazard light switch controls the operation of the hazard lights. Move the turn signal switch up or down to turn off the hazard lights.

POSITION	FUNCTION
Out	On
In	Off




HEADLIGHT SWITCH



The headlight switch controls the operation of the headlights.

POSITION	FUNCTION
Тор	On
Bottom	Off

HORN




The horn button is used to control the horn. The horn button is spring loaded to stay in the off position. Push and hold the horn button to operate the horn.

Note: The horn will not operate when the key switch is OFF.



KEY SWITCH



The key switch controls the motor and electrical system. A key is used to select the key switch position. The key can only be inserted or removed when the key switch set to OFF.



Page 26

POSITION	CONDITION	
OFF	Normal position when the vehicle is not in use. Electrical power from the batteries is not available to power the motor or electrical systems. <i>Note:</i> Some electrical accessories operate independently of the key switch.	
ON	Normal position when the vehicle is in use. Electrical power from the batteries is available to power the motor and electrical systems.	

PARK BRAKE

FAILURE TO ENGAGE THE PARK BRAKE CAN CAUSE PROPERTY DAMAGE AND PERSONAL INJURY. AFTER THE VEHICLE STOPS, ENGAGE THE PARK BRAKE UNTIL IT IS FULLY ENGAGED AND PREVENTS THE VEHICLE FROM MOVING.

UNINTENDED VEHICLE OPERATION CAN CAUSE SERIOUS PERSONAL INJURY OR DEATH. THE PARK BRAKE WILL RELEASE AUTOMATICALLY WHEN THE ACCELERATOR OR BRAKE PEDAL IS PUSHED. PREVENT ACCIDENTAL ACCELERATOR OR BRAKE PEDAL ACTUATION.



The park brake is a variable position control that is used to make sure that a vehicle does not move while parked.

Push the park brake firmly to engage the park brake.

To disengage the park brake, push the accelerator or brake pedal.

RUN/TOW SWITCH

UNINTENDED VEHICLE MOVEMENT CAN CAUSE SERIOUS PERSONAL INJURY OR DEATH. WHEN THE RUN/TOW SWITCH IS IN THE TOW POSITION, ALL MOTOR BRAKING FUNCTIONS, INCLUDING WALK-AWAY BRAKING, ARE DISABLED.



The Run/Tow switch is used during towing, maintenance, or extended storage. Set the switch to RUN for normal operation. Set the switch to TOW for maintenance, extended storage, or when towed.

Wait 10 seconds before vehicle operation when the switch is set from TOW to RUN.

Do not quickly operate the switch from RUN to TOW and back to RUN. Wait 10 seconds to set the switch to RUN.





POSITION	FUNCTION	
RUN	Normal Operation	
тоw	 Connect the battery cables. Disconnect the battery cables. To do vehicle maintenance. Put the vehicle into extended storage. Tow the vehicle. 	


TURN SIGNAL LEVER



The turn signal lever controls the operation of the turn signal lights. The turn signal light will flash when turned on.

POSITION	FUNCTION
Down	Left
Center	Off
Up	Right

WINDSHIELD WIPER SWITCH



The windshield wiper switch controls the operation of the wiper blades.

Note: The windshield wiper operates independently of the key switch position.

POSITION	FUNCTION
Тор	On
Bottom	Off

MODULAR CAB CONTROLS

DEFROST AND HEATER SWITCH



lub Car

The defrost and heater switch controls the operation of the defrost and heater system.

Note: The defrost and heater system will only operate when the lower dash fan switch is set to low or high.

POSITION	FUNCTION
Тор	On
Bottom	Off

DOME LIGHT SWITCH



The dome light switch controls the operation of the interior cabin lights.

Note: The dome light operates independently of the key switch position.

POSITION	FUNCTION
I	On
О	Off

LOWER DASH FAN SWITCH



The lower dash fan switch controls the operation of the lower dash fan.

Note: The lower dash fan operates independently of the key switch position.

POSITION	FUNCTION
н	High
OFF	Off
L	Low

STROBE LIGHT SWITCH



The strobe light switch controls the operation of the strobe light.

POSITION	FUNCTION
Тор	On
Bottom	Off

UPPER CAB FAN SWITCH



The upper cab fan switch controls the operation of the upper cab fan.

Note: The upper cab fan operates independently of the key switch position.

POSITION	FUNCTION
Тор	On
Bottom	Off




WINDSHIELD WASHER SWITCH




The windshield washer switch controls the operation of the washer fluid supply to the windshield. The switch is spring loaded to stay in the off position. Push and hold the switch in the on position to apply washer fluid to the windshield.





VEHICLE FEATURES







VEHICLE FEATURES DESCRIPTION

The vehicle features listed are standard and optional.

ELECTRIC BED LIFT

USE CAUTION WHEN WORKING UNDER THE BED. MAKE SURE \Lambda DANGER THAT THE PROP ROD IS SECURE. OTHERWISE THE BED WILL FALL, RESULTING IN SEVERE PERSONAL INJURY OR DEATH. THE ELECTRIC CARGO BED CAN LOWER WITHOUT POWER AND CAUSE PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH. BEFORE YOU DO THE SERVICING OF THE BED LIFT SYSTEM, **REMOVE THE ELECTRIC CARGO BED. INCORRECT OPERATION OF THE CARGO BED CAN CAUSE** PERSONAL INJURY OR DEATH. KEEP ALL PERSONS CLEAR OF THE CARGO BED AREA WHEN THE CARGO BED IS LIFTED, LOWERED, **OR DURING MAINTENANCE. KEEP HANDS CLEAR OF ALL CRUSH** AREAS. DO NOT LET THE CARGO BED FALL. BEFORE THE CARGO BED IS LIFTED, REMOVE ALL CARGO AND ACCESSORIES FROM THE CARGO BED. CORRECTLY ENGAGE THE PROP ROD. **CAREFULLY LOWER THE CARGO BED.**



THE AREA BETWEEN THE CARGO BED AND SEAT BACK SUPPORT CAN CRUSH. KEEP HANDS AND FINGERS AWAY FROM THIS AREA.

The electric bed lift lowers and lifts the tilt cargo bed. The electric bed lift is controlled through the electric bed lift switch.

ELECTRIC BED LIFT CAPACITY

The electric bed lift has a maximum capacity of 500 lb (226 kg).

OPERATION

LIFT THE ELECTRIC BED LIFT

- 1. Turn the key to ON.
- 2. Push and hold the electric bed lift switch in the top position.

LOWER THE ELECTRIC BED LIFT

- 1. Turn the key to ON.
- 2. Push and hold the electric bed lift switch in the bottom position.
- 3. Release the electric bed lift switch when the electric bed lift makes a clicking sound.

MODULAR CAB

The modular cab is available in different configurations for a wide range of operator requirements. The modular cab has many accessories to select from. Speak with your local approved dealer or distributor for a full list of accessories and configurations.

The Curtis modular cab is supported by Curtis Industries, LLC. Call 508-853-2200 for parts and service.



TILT CARGO BED

MARGER USE CAUTION WHEN WORKING UNDER THE BED. MAKE SURE THAT THE PROP ROD IS SECURE. OTHERWISE THE BED WILL FALL, RESULTING IN SEVERE PERSONAL INJURY OR DEATH. INCORRECT OPERATION OF THE CARGO BED CAN CAUSE PERSONAL INJURY OR DEATH. KEEP ALL PERSONS CLEAR OF THE CARGO BED AREA WHEN THE CARGO BED IS LIFTED, LOWERED, OR DURING MAINTENANCE. KEEP HANDS CLEAR OF ALL CRUSH AREAS. DO NOT LET THE CARGO BED FALL. BEFORE THE CARGO BED IS LIFTED, REMOVE ALL CARGO AND ACCESSORIES FROM THE CARGO BED. CORRECTLY ENGAGE THE PROP ROD. CAREFULLY LOWER THE CARGO BED.

🗥 WARNING

THE AREA BETWEEN THE CARGO BED AND SEAT BACK SUPPORT CAN CRUSH. KEEP HANDS AND FINGERS AWAY FROM THIS AREA.


A tilt cargo bed makes the removal of cargo easier and gives additional access for vehicle maintenance. The cargo bed release handle is used to unlock the cargo bed from its stowed position. The prop rod is used to hold the lifted cargo bed in position.

Note: An optional electric bed lift is available.

OPERATION

LIFT THE TILT CARGO BED

- 1. Disable the vehicle.
- 2. Pull the bed latch handle.




3. Lift the bed.








4. Make sure that the prop rod (1) is in a notch (2).



LOWER THE TILT CARGO BED

- 1. Lift the tilt cargo bed.
- 2. Remove the prop rod (3) from the notch (4).



- 3. Lower the tilt cargo bed.
- 4. Make sure that the cargo bed latch engages.

12-VOLT POWER RECEPTACLE



The 12-volt 6.5-amp power receptacle supplies electricity to power and charge accessories when the key switch is ON. The 12-volt power receptacle and the electrical circuit is protected by a 10 amp fuse.

- *Note:* The continuous operation of the 12-volt power receptacle can cause in a full discharge of vehicle batteries.
- *Note:* Do not use the 12-volt power receptacle for long periods of time when the engine is off.


VERSATTACH SYSTEM

VersAttach is a track-based attachment system that organizes and secures cargo bed accessories. Speak with your local approved dealer or distributor for a full list of accessories and configurations.





(Page intentionally left blank.)





BATTERY CHARGER





DANGER	A BATTERY CHARGER, CORD, PLUG, OR VEHICLE CHARGER RECEPTACLE THAT HAS DAMAGE OR A BAD ELECTRICAL CONNECTION CAN CAUSE A FIRE, PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH. DO NOT CONNECT THE BATTERY CHARGER TO AN AC POWER SOURCE. DO NOT TRY TO REPAIR THE BATTERY CHARGER, CORD, PLUG, OR VEHICLE CHARGER RECEPTACLE. SPEAK WITH YOUR LOCAL DEALER OR DISTRIBUTOR FOR REPAIRS.
	INCORRECT CONNECTION OF THE AC CORD CAN CAUSE A FIRE OR AN ELECTRICAL SHOCK. DO NOT USE AN ADAPTER TO CONNECT THE AC CORD INTO A TWO-PRONG POWER SOURCE. CONNECT THE AC CORD TO AN APPROVED POWER SOURCE.
	CONNECTION OF THE AC CORD TO AN INCORRECT RECEPTACLE CAN CAUSE A FIRE OR AN ELECTRICAL SHOCK. CONNECT THE AC CORD TO AN APPROVED POWER SOURCE AND RECEPTACLE.
	A BATTERY CHARGER CORD, PLUG, OR VEHICLE CHARGER PORT THAT HAS DAMAGE OR A BAD ELECTRICAL CONNECTION CAN CAUSE A FIRE, PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH. DO NOT USE A BATTERY CHARGER THAT HAS DAMAGE, FELL, OR WAS HIT. PUT THE CORDS IN AN AREA TO PREVENT THEM FROM BEING STEPPED ON, TRIPPED OVER, OR SUBJECTED TO DAMAGE OR STRESS. SPEAK WITH YOUR LOCAL DEALER OR DISTRIBUTOR FOR REPAIRS.
	LIQUID ON THE BATTERY CHARGER CAN CAUSE PROPERTY DAMAGE, ELECTRICAL SHOCK, PERSONAL INJURY, OR DEATH. DO NOT LET THE BATTERY CHARGER BECOME WET. KEEP THE BATTERY CHARGER DRY.
NOTICE	IF THE BATTERIES ARE REPLACED WITH A DIFFERENT BRAND OR TYPE, BATTERY DAMAGE CAN OCCUR. UPDATE THE BATTERY CHARGER ALGORITHM WHEN A DIFFERENT BRAND OR TYPE OF BATTERY IS INSTALLED. SPEAK WITH YOUR LOCAL APPROVED DEALER OR DISTRIBUTOR TO UPDATE THE BATTERY CHARGER ALGORITHM.
	A LIGHTNING STRIKE CAN CAUSE ELECTRICAL COMPONENT DAMAGE. A SURGE ARRESTOR CAN HELP PROTECT ELECTRICAL COMPONENTS. INSTALL A SURGE ARRESTOR ON THE AC CORD.

INTRODUCTION

The Efficient, Reliable, Intelligent, and Connected (ERIC) battery charger is a high-frequency charger that includes many benefits:

EFFICIENT	 Maximum 91% battery charging efficiency. 7.5 maximum AC amperage that lets for two chargers to operate on one 20-amp circuit. Automatically checks and charges the batteries. Lets the charger to be connected to the vehicle during extended storage.
RELIABLE	 Sealed aluminum housing prevents environmental contaminate damage to internal charger components. Operates across a wide range of input voltage range.
INTELLIGENT	Status indicator lights to identify AC power, stages of charge, and faults.Visual signal when charging starts.
CONNECTED	 Two-way data communication through a USB receptacle. Update the charger with the latest charge algorithm. Collect status and condition data for charger monitoring.

ERIC IC650 SPECIFICATIONS

MANUFACTURER INFORMATION

Manufacturer	Delta Q Technologies
Model Name	ERIC
Model Number	IC650-048-CC - without display panel IC650-048-COMM - with display panel

DIMENSION AND WEIGHT

Dimension	9.9 in (25.1 cm) length 7.3 in (18.5 cm) width 3.1 in (7.9 cm) height
Weight	5.3 lb (2.4 kg)

OPERATIONAL TEMPERATURE

Temperature Range	-40° F to 104° F (-40° C to 40° C)
-------------------	------------------------------------



AC INPUT

Voltage	85 to 270 VAC minimum/maximum 100 to 240 VAC maximum efficiency range
Current	7.5 A maximum
Frequency	50 to 60 Hz

DC OUTPUT

Voltage	48 VDC nominal 72 VDC maximum
Current	13.5 A maximum

GOVERNMENTAL AND INDUSTRY CERTIFICATIONS

EUROPEAN CONFORMITY

The battery charger is European conformity (CE) certified per EU 2014/30/EU Electromagnetic Compatibility Directive, 2014/35/EU Low Voltage Equipment Directive, 2014/65/EU Restriction of Hazardous Substances Directive, LV Directives EN 60335-1:2012 and EN 60335-2-29:2004, and EMC Directives EN 61000-3-2: 2014, EN 61000-3-3: 2013, EN 61000-6-2: 2005, EN 61000-6-4: 2007.

FEDERAL COMMUNICATIONS COMMISSION

The battery charger is Federal Communications Commission (FCC) certified.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in an industrial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

INTERNATIONAL PROTECTION MARKING

The battery charger has an International Protection Marking (IP) certification of IP66.

The battery charger enclosure has an International Protection Marking (IP) certification of IP46.

The battery charger USB receptacle with the dust cover has an International Protection Marking (IP) certification of IP66.

The AC supply connector has an International Protection Marking (IP) certification of IP20.

Note: The AC supply connector is applicable for indoor use only. Keep all AC connections clean and dry.



UNDERWRITERS LABORATORIES AND CANADIAN STANDARDS ASSOCIATION

Listed by Underwriters Laboratories (UL) and Canadian Underwriters. Meets the criteria of the Canadian Standards Association (CSA).

FEATURES

AC ELECTRICAL CORD AND PLUG

The AC electric cord has an equipment-grounding conductor and grounding type plug. The AC plug must be connected to a correctly rated ground fault circuit interrupter (GFCI) receptacle with arc flash protection. The receptacle must be installed and grounded in accordance with the National Electrical Code, local codes, and local ordinances.

\land WARNING


AN EXTENSION CORD IS NOT RECOMMENDED. INCORRECT CONNECTION OF THE CHARGER AC CORD TO AN EXTENSION CORD CAN CAUSE A FIRE OR AN ELECTRICAL SHOCK.

Use of an extension cord with the charger is not recommended. Precautions when the use of an extension cord is necessary:

- The extension cord must accept a three-prong plug.
- The extension cord must be as short as possible and not exceed 12 ft (3.7 m).
- The extension cord must be a three-wire No. 12-AWG (American Wire Gauge) or No. 14-SWG (British Standard Wire Gauge).
- Make sure that cords will not be stepped on, tripped over, or subject to damage or stress.

STATUS INDICATOR LIGHTS

The status indicator lights give the AC power availability, charge status, and charger condition.





SYMBOL		STATUS	CONDITION
		Red (Constant)	Charger fault condition. See the display panel for more information.
		Orange (Flash On And Off)	External fault condition. See the display panel for more information.
		Green (Flash On And Off)	The USB receptacle is on. Do not remove the USB flash drive.
		Green (Constant)	Safe to remove the USB flash drive.
		Green (Constant)	Charging is complete. Batteries are fully charged.
		Green (Flash On And Off)	
		Green (Constant)	Charging. Batteries are at high state of charge (SOC).
	<u> </u>	Off	
		Green (Flash On And Off)	Charging. Batteries are not at a high SOC.
		Blue (Constant)	There is AC power to charger.

The table below is for battery chargers with a display panel.



Features

5

SYMBOL	STATUS	CONDITION
ZZ	Yellow (Constant)	The charger output is on. There is a risk of electric shock.
Display Panel	F code	Internal fault condition caused the charge process to stop. See note.
	E code	External fault condition caused the charge process to stop. See note.
	P code	The charger program mode is in operation.
	USB code	The USB receptacle is on. Do not remove the USB flash drive.

Note: Speak with your dealer or distributor.

BATTERY CHARGING INTERLOCK

<u>External Battery Charger</u>: The battery charging interlock is a safety feature that prevents possible damage to the battery charger and vehicle. The battery charging interlock will automatically engage when the DC cord is connected to the vehicle. The vehicle will not operate when the DC cord is connected.

Note: The AC cord does not have to be connected for the battery charging interlock to operate.

<u>Onboard Battery Charger</u>: The battery charging interlock is a safety feature that prevents possible damage to the battery charger and vehicle. The battery charging interlock will automatically engage when the AC cord is connected to a power source. The vehicle will not operate when the AC cord is connected.

EXTERNAL BATTERY CHARGER MOUNTING

IF THE BATTERY CHARGER IS NOT CORRECTLY ATTACHED, IT CAN FALL AND CAUSE DAMAGE AND PERSONAL INJURY. DO NOT HANG THE BATTERY CHARGER BY ITS HANDLE OR CORD. CORRECTLY ATTACH THE BATTERY CHARGER.

Note: This section is applicable to an external battery charger. The onboard battery chargers are installed on the vehicle.

Mount the external battery charger in a position that gives it sufficient airflow and the indicator lights are visible.






A strain relief and drip loop is necessary to prevent damage to the charger. The strain relief prevents tension on the AC plug. The drip loop prevents water damage to the AC plug.

HOW TO MAKE STRAIN RELIEF AND DRIP LOOP

A strain relief and drip loop is necessary to prevent damage to the charger. The strain relief prevents tension on the AC plug. The drip loop prevents water damage to the AC plug.

1. Connect the AC cord (1) into the AC plug.



- 2. Supply sufficient AC cord to make a drip loop and strain relief.
- 3. Secure the AC cord to the battery charger with a plastic cable tie (2).

INSPECTION AND MAINTENANCE

ELECTRICAL CORDS

NOTICE

AN ELECTRICAL SHORT IN THE DC CORD CAN CAUSE THE 30 AMP FUSE TO BLOW. IF THERE IS DAMAGE TO THE DC CORD, SPEAK WITH YOUR LOCAL DEALER OR DISTRIBUTOR.

Examine electrical cords for wear and damage before use. Immediately replace electrical cords for:

- Cracks
- Cuts
- Frayed wiring
- Insulation damage
- Loose connections
- Splices

Make sure that the DC electrical cord has the warning tag attached and that the warning tag is readable. Replace a missing or damaged warning tag immediately.



ELECTRICAL PLUGS AND RECEPTACLES

NOTICE

IF THE PLUG PINS ARE BENT, SPEAK WITH YOUR LOCAL DEALER OR DISTRIBUTOR FOR REPAIRS. DO NOT TRY TO REPAIR THE AC CORD PLUG OR PINS.

Examine electrical plugs for wear and damage before use. Immediately replace electrical plugs for:

- Bent pins
- Corrosion
- Cracks
- Loose connections
- Missing pins
- Worn pins

CLEAN THE ELECTRICAL PLUGS AND RECEPTACLES

🛝 DANGER

LUBRICATING THE PLUG AND RECEPTACLE WITH THE AC CORD CONNECTED TO A POWER SOURCE CAN CAUSE PROPERTY DAMAGE, ELECTRICAL SHOCK, SERIOUS INJURY, AND DEATH. DO NOT LUBRICATE THE PLUG AND VEHICLE CHARGER RECEPTACLE WITH THE AC CORD CONNECTED TO A POWER SOURCE.

- 1. Disconnect the AC cord from the power source.
- 2. Disconnect the AC cord from the battery charger.
- 3. Disconnect the DC cord from the vehicle charger receptacle.
- 4. Apply electrical contact cleaner to the electrical plugs and receptacles. Refer to the manufacturer instructions.
- 5. Clean the electrical plugs and receptacles.
- 6. Lubricate the electrical plugs and receptacles with WD-40[®].

BATTERY CHARGER USB RECEPTACLE

The movement of charger data and download of the charge algorithm is done through the USB receptacle. Use of the USB receptacle is for approved persons and technicians. If the batteries are replaced with a different brand or type, speak with your dealer or distributor to update the battery charger algorithm.

The USB receptacle can have intermittent connectivity because of environmental contaminates. Always install the USB dust cover to protect the USB receptacle.

CLEAN THE USB RECEPTACLE


- 1. Disconnect the DC cord from the vehicle charger receptacle.
- 2. Disconnect the AC cord from the power source.
- 3. Carefully remove large contaminates.
- 4. Use compressed air in short intervals to remove dust and smaller contaminates.
- 5. Clean the port with a cotton swab and rubbing alcohol or electronics cleaner solvent. Let sufficient time for the alcohol or solvent to dry.





- 6. If contamination continues, apply dielectric grease to the USB receptacle.
- 7. Install the USB dust cover.





VEHICLE SPECIFICATIONS



DIMENSIONS

6

Length	110.1 in (279.6 cm) - standard bed 111.9 in (284.2 cm) - standard bed and brush guard
Width	50.3 in (127.7 cm) 62.6 in (159.0 cm) - with mirrors
Height	47.1 in (119.6 cm) - at the steering wheel 70.7 in (179.5 cm) - with canopy 74.3 in (188.7 cm) - with cab 12.5 in (31.7 cm) - floorboard height
Bed Height	29.5 in (74.9 cm)
Box Bed Size	37 x 47.5 x 10.5 in (93.9 x 120.6 x 26.6 cm)
Flat Bed Size	36.5 x 48.8 in (92.7 x 123.9 cm)
Ground Clearance	5.2 in (13.2 cm)
Wheel Tread	36.6 in (92.9 cm) - front wheel 39.5 in (100.3 cm) - rear wheel

PERFORMANCE

Forward Speed (On Level Ground)	15 to 17 mph (24 to 27 km/h)
Turning Radius (SAE J695)	108.7 in (276.2 cm)
Intersecting Aisle Clearance	87 in (221.0 cm)
Curb-To-Curb	230.5 in (585.4 cm)
Wall-To-Wall	Unknown At Time Of Print

TIRES

Go to the approved wheel and tire assemblies matrix on http://www.clubcar.com for information regarding tire type, inflation pressure, and lugnut torque.

ELECTRIC MOTOR

Motor Type	48V DC motor
Motor Horsepower	3.3 hp (2.5 kW)

BATTERIES

Battery Type	8V high capacity deep cycle flooded lead acid
Battery Quantity	6

NOISE AND VIBRATION

Drive-by Noise Level To Operator (EN 12053-2001)	66.6 dBA (±2)
Vibration At Driver's Seat (EN 13059-2002)	0.5 (m/s ²) ² (±0.16)

TRANSAXLE

Fluid Capacity

22 fl-oz (0.67 l)

VEHICLE WEIGHTS AND LOAD CAPACITIES

IF THE RATED CAPACITIES OF THE VEHICLE ARE EXCEEDED, PROPERTY DAMAGE, SERIOUS PERSONAL INJURY, OR DEATH CAN OCCUR. DO NOT EXCEED THE RATED CAPACITY OF THE VEHICLE. RATED CAPACITY IS FOR LEVEL SURFACES ONLY.

TOO MUCH WEIGHT IN THE VEHICLE CAN AFFECT THE VEHICLES HANDLING, OR CAUSE COMPONENT FAILURE, RESULTING IN LOSS OF CONTROL OF VEHICLE AND SERIOUS PERSONAL INJURY. DO NOT EXCEED THE VEHICLE LOAD CAPACITIES.

DO NOT TOW WHEN THE CARGO CAPACITY IS EXCEEDED.

Description	Weight
Vehicle Dry Weight	885 lb (401.4 kg)
Vehicle Curb Weight	1105 lb (501.2 kg)
Occupant Capacity	500 lb (226.8 kg)
Cargo Capacity	300 lb (136.1 kg)
Maximum Towing Weight	1105 lb (501.2 kg)
Trailer Tongue Weight	150 lbf (667 N)



Description	Weight
Gross Trailer Weight	800 lb (363 kg)
Vehicle Rated Capacity	800 lb (362.9 kg)
Vehicle Combination Rated Capacity	800 lb (362.9 kg)
Maximum Gross Vehicle Weight	1905 lb (863.2 kg)
Maximum Gross Vehicle Combination Weight	1905 lb (863.2 kg)

TERM	DEFINITION
Vehicle Dry Weight	The vehicle dry weight is the weight of the vehicle with no batteries.
Vehicle Curb Weight	The vehicle curb weight is the weight of the vehicle with the batteries installed.
Occupant Capacity	The occupant capacity is the maximum permitted weight for occupants to operate the vehicle safely.
Cargo Capacity	The cargo capacity is the maximum weight of a load that the vehicle can have in the cargo area. The cargo capacity includes the weight of optional equipment.
Maximum Towing Weight	The maximum towing weight is the maximum weight the vehicle can tow with a Club Car approved tow kit.
Trailer Tongue Weight	The trailer tongue weight is the maximum permitted weight applied by the trailer tongue onto the trailer hitch.
Gross Trailer Weight	The gross trailer weight is the trailer weight plus the weight of the load on the trailer.
Vehicle Rated Capacity	The vehicle rated capacity is the maximum weight on the vehicle. This capacity includes the weight of: bed load, cargo, occupants, and optional equipment.
Vehicle Combination Rated Capacity	The vehicle combination rated capacity is the maximum weight on the vehicle with a trailer. This capacity includes: vehicle rated capacity and the gross trailer weight.
Maximum Gross Vehicle Weight	The maximum gross vehicle weight is the vehicle weight plus the vehicle rated capacity.
Maximum Gross Vehicle Combination Weight	The maximum gross vehicle combination weight is the maximum gross vehicle weight plus the gross trailer weight.



VEHICLE OPERATION



A DANGER	THE VEHICLE HAS A HIGHER RISK OF INJURY OR DEATH IN COLLISIONS THAN A CAR, VAN, OR TRUCK. THE HIGHER THE SPEED OF TRAFFIC, THE HIGHER THE RISK OF INJURY. DO NOT OPERATE THE VEHICLE IN A MANNER THAT IMPEDES TRAFFIC. OPERATE THE VEHICLE ONLY ON ROADS LIMITED TO LOW-SPEED VEHICLES.
	OPERATING THE VEHICLE WHILE OCCUPANTS ARE NOT FULLY SEATED CAN CAUSE SERIOUS PERSONAL INJURY OR DEATH. START THE VEHICLE ONLY WHEN ALL OCCUPANTS ARE FULLY SEATED.
	FALLING OBJECTS CAN CAUSE PROPERTY DAMAGE, SERIOUS PERSONAL INJURY, OR DEATH. DO NOT OPERATE THE VEHICLE WHERE THERE IS A RISK OF FALLING OBJECTS.
	DO NOT LET CHILDREN THAT REQUIRE A CHILD SAFETY SEAT TO RIDE IN THE VEHICLE.
	DO NOT LET A PASSENGER HOLD A CHILD ON THEIR LAP WHILE THE VEHICLE IS IN OPERATION.
	NEVER ALLOW PASSENGERS TO RIDE IN THE VEHICLE OR TRAILER BEING TOWED. DO NOT LET PASSENGERS RIDE IN THE VEHICLE OR TRAILER BEING TOWED.
	DO NOT LET PASSENGERS RIDE IN THE CARGO BED.
	KEEP AWAY FROM DROP-OFFS, STEEP SLOPES, AND UNSTABLE SURFACES.
	THE VEHICLE IS NOT DESIGNED TO BE USED ON PUBLIC ROADS. DO NOT LICENSE THE VEHICLE FOR PUBLIC ROADS. DO NOT OPERATOR THE VEHICLE ON PUBLIC ROADS.
	SUDDEN STARTS, STOPS, AND TURNS CAN CAUSE PERSONAL INJURY AND VEHICLE DAMAGE. PREVENT SUDDEN STARTS, STOPS, AND TURNS.
	FAILURE TO MAKE NECESSARY REPAIRS CAN CAUSE A FIRE, PROPERTY DAMAGE, SERIOUS PERSONAL INJURY, OR DEATH. IF PROBLEMS ARE FOUND DURING SCHEDULED INSPECTION OR SERVICE, OPERATE THE VEHICLE ONLY WHEN REPAIRS ARE MADE.
	MAKE SURE THAT ALL PASSENGERS CAN SECURE THEMSELVES IN THE VEHICLE BEFORE VEHICLE OPERATION.
	TO PREVENT SERIOUS INJURY, KEEP THE ENTIRE BODY IN THE VEHICLE DURING OPERATION.
	THE VEHICLE IS NOT SPECIALLY EQUIPPED FOR HANDICAPPED PERSONS. BEFORE VEHICLE OPERATION, MAKE SURE THAT ALL PERSONS COMPLY WITH THE WARNINGS AND OPERATING INSTRUCTIONS.

INCORRECT OPERATION OF THE VEHICLE CAN CAUSE DECREASED VEHICLE PERFORMANCE, SERIOUS PERSONAL INJURY, OR DEATH.

Club Car

FAILURE TO CORRECTLY MAINTAIN THE VEHICLE CAN CAUSE DECREASED VEHICLE PERFORMANCE, SERIOUS PERSONAL INJURY, OR DEATH.

TO PREVENT FALLS FROM THE VEHICLE, PASSENGERS MUST STAY SEATED AND ALWAYS HOLD ON TO HAND HOLDS OR HANDRAILS WHEN THE VEHICLE IS IN OPERATION. THE DRIVER MUST KEEP BOTH HANDS ON THE STEERING WHEEL WHEN THE VEHICLE IS IN OPERATION.

A SHARP TURN AT HIGH SPEEDS CAN CAUSE A ROLL-OVER, FALL, PROPERTY DAMAGE, AND SERIOUS INJURY. OPERATE THE VEHICLE SLOWLY IN TURNS.

UNINTENDED VEHICLE OPERATION CAN CAUSE SERIOUS PERSONAL INJURY OR DEATH. BEFORE LEAVING OR VEHICLE MAINTENANCE, DISABLE THE VEHICLE.

THE VEHICLE IS NOT DESIGNED TO MEET CHILD SAFETY SEAT COMPATIBILITY REQUIREMENTS. CHILDREN REQUIRING A CHILD SAFETY SEAT MUST NOT RIDE ON THE VEHICLE. COMPLY WITH STATE AND LOCAL LAWS PERTAINING TO CHILD SAFETY.

THIS VEHICLE IS NOT INTENDED FOR USE BY PERSONS, INCLUDING CHILDREN WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES, OR LACK OF EXPERIENCE AND KNOWLEDGE, UNLESS THEY HAVE BEEN GIVEN SUPERVISION OR INSTRUCTION CONCERNING USE OF THE APPLIANCE BY A PERSON RESPONSIBLE FOR THEIR SAFETY. CHILDREN SHOULD BE SUPERVISED TO ENSURE THAT THEY DO NOT PLAY WITH THE VEHICLE.

CAUTION

OPERATE THE VEHICLE ONLY FROM THE DRIVERS SEAT.

OPERATE THE VEHICLE ONLY IN SPECIFIED AREAS.

ONLY AN AUTHORIZED LICENSED DRIVER CAN OPERATE THE VEHICLE.

ONLY OPERATE THE VEHICLE IN COMPLIANCE WITH LOCAL AND STATE LAWS.

USE CAUTION WHEN OPERATING THE VEHICLE IN THE PRESENCE OF HIGHER-SPEED VEHICLES, IN CONGESTED AREAS, OR ON UNIMPROVED SURFACES.

DAILY PRE-OPERATIONAL SAFETY AND PERFORMANCE CHECKS

OVERVIEW

Use the daily pre-operational checklist and vehicle performance inspection to inspect the operational condition and performance of the vehicle.

If a vehicle is found to be in bad operational condition, remove it from operation. Removal from operation will prevent more damage to the vehicle and prevent a serious injury.

If the vehicle is removed from operation, speak with your dealer or distributor for maintenance and repairs.



DAILY PRE-OPERATIONAL SAFETY CHECKLIST

INSPECTION AREA	INSPECTION CRITERIA
	 Make sure that all parts are correctly installed.
General	 Make sure that all nuts, bolts, and screws are tight.
	Replace missing, worn, or damaged items.
	 Make sure all safety, regulatory, and marketing decals are correctly installed.
Decals	Clean the decals with a soft moist cloth.
	Replace missing, worn, or damaged decals.
	Examine for wear and damage.
Tires	Replace worn or damaged tires.
	Inflate tires as necessary.
	 Make sure that all battery hold-downs are tight.
Batteries	 Make sure that the battery cables are correctly attached. Tighten as necessary.
	 Examine the battery posts for corrosion. If corrosion is found, remove the corrosion.
	 Make sure that the batteries are fully charged.
	 Examine the battery acid level. Add deionized or distilled water as necessary.
	 Replace missing, worn, or damaged items.
	 Examine the electrical cords for cracks, loose connections, and frayed wires.
Battery Charger	Examine receptacle contacts and plug terminals. Clean as necessary.
	Replace missing, worn, or damaged items.
	 Make sure that the battery charger operates correctly.
Vehicle Performance Inspection	Do a vehicle performance inspection.

VEHICLE PERFORMANCE INSPECTION

Before the vehicle performance inspection:

- Read and obey all safety decals and information located on the vehicle.
- Understand how to operate the vehicle correctly and safely.

Club Car

- Front wheels are turned in the direction of travel.
- No obstructions are in the vehicle's path.

During the vehicle performance inspection:

- Listen for unusual noises such as squeaks or rattles.
- Examine the ride and performance of the vehicle.
- Examine the steering. The vehicle must be easy to steer and must not have play in the steering wheel.
- The vehicle must stop smooth and straight. The brake pedal must not be able to be pushed to the floorboard. Have a trained technician do a brake system check if:
 - The vehicle swerves.
 - The brake pedal goes more than half the distance to the floorboard with moderate pressure applied.
 - The vehicle does not stop.

To do the vehicle performance inspection:

- 1. Turn the key to ON.
- 2. Push and hold the brake pedal.
- 3. Set the Forward / Neutral / Reverse control (FNR) to R. Make sure that the multi-purpose buzzer operates.
- 4. Release the brake pedal.
- 5. Slowly push the accelerator pedal. Make sure the vehicle moves in reverse.
- 6. Slowly push the brake pedal. Stop the vehicle.
- 7. Set the FNR to F. Make sure that the multi-purpose buzzer does not operate.
- 8. Release the brake pedal.
- 9. Slowly push the accelerator pedal. Make sure that the vehicle moves forward.
- 10. Operate the vehicle to full speed.
- 11. Release the accelerator pedal. Make sure:
 - 11.A The accelerator pedal goes back to its initial position.
 - 11.B Make sure that the regenerative braking functions normally.
- 12. Slowly push the brake pedal. Stop the vehicle.
- 13. Park the vehicle on a level surface.
- 14. Disengage the park brake.
- 15. Try to push the vehicle to engage the walk-away braking. Walk-away braking is engaged when:
 - 15.A The multi-purpose buzzer operates.
 - *Note:* Regenerative braking operates and limits the vehicle speed to no more than 1 to 3 mph (1.6 to 4.8 km/h).
- 16. Stop the vehicle.



- 17. Park the vehicle on a grade of 20% or less. Make sure that the park brake holds the vehicles position.
- 18. Slowly push the accelerator pedal. Increase the vehicle to maximum speed down a grade of 20% or less.
- 19. Make sure regenerative braking engages at the maximum programmed speed and limits the vehicle to its maximum programmed speed.
- 20. Slowly push the brake pedal. Stop the vehicle. Make sure regenerative braking disengages when the vehicle speed is below the maximum programmed top speed.

VEHICLE MOVEMENT

OVERVIEW

Operate the vehicle only after you read, understand, and know:

- The Driving Instructions
- Indicators
- Gauges
- Displays
- Controls

MOTOR START

Before motor start:

- Read and obey all safety decals and information located on the vehicle.
- Understand how to operate the vehicle correctly and safely.
- Understand the function of all vehicle controls, indicators, displays, and gauges.
- Make sure that all passengers are seated and use the hand holds or handrails. The operator must have both hands on the steering wheel.
- Front wheels are turned in the direction of travel.
- No obstructions are in the vehicle's path.
- Forward / Neutral / Reverse control (FNR) is set to N.
- The park brake is set.
- The accelerator pedal is not pushed.
- The vehicle is at a full stop.

To start the motor:

- 1. Put the key into the key switch.
- 2. Turn the key to ON. Push the accelerator pedal to start the motor.
- 3. Turn the key to MODE 2. Push the accelerator pedal to start the motor.

TURN OFF MOTOR

1. Release the accelerator pedal.

- 2. Stop the vehicle.
- 3. Push and hold the brake pedal.
- 4. Set the Forward / Neutral / Reverse control (FNR) to N.
- 5. Turn the key to OFF.
- 6. Engage the park brake to lock the wheels.
- 7. Remove the key. Keep the key in a safe area.

FORWARD MOVEMENT

WARNING

FAILURE TO DECREASE THE VEHICLE SPEED IN BAD DRIVING CONDITIONS CAN CAUSE PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH. DECREASE THE VEHICLE SPEED WHEN IN BAD DRIVING CONDITIONS SUCH AS WET GRASS OR ROUGH TERRAIN.

Before forward movement:

- Read and obey all safety decals and information located on the vehicle.
- Understand how to operate the vehicle correctly and safely.
- Understand the function of all vehicle controls, indicators, displays, and gauges.
- Make sure that all passengers are seated and use the hand holds or handrails. The operator must have both hands on the steering wheel.
- Make sure that the front wheels are turned in the direction of travel.
- Make sure that there are no obstructions are in the vehicles path.
- The key switch is set to ON.
- The vehicle is at a full stop.

To move the vehicle forward:

- 1. Set the Forward / Neutral / Reverse control (FNR) to F.
- 2. Disengage the park brake.
- 3. Slowly push the accelerator pedal.


REVERSE MOVEMENT

🗥 WARNING

FAILURE TO DECREASE THE VEHICLE SPEED WHEN IN REVERSE CAN CAUSE PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH. DECREASE THE VEHICLE SPEED WHEN IN REVERSE AND PREVENT SUDDEN STOPS.

Before reverse movement:

- Read and obey all safety decals and information located on the vehicle.
- Understand how to operate the vehicle correctly and safely.
- Understand the function of all vehicle controls, indicators, displays, and gauges.



- Make sure that all passengers are seated and use the hand holds or handrails. The operator must have both hands on the steering wheel.
- Make sure that the front wheels are turned in the direction of travel.
- Make sure that there are no obstructions are in the vehicles path.
- The key switch is set to ON.
- The vehicle is at a full stop.

To move the vehicle in reverse:

- 1. Set the Forward / Neutral / Reverse control (FNR) to R. Make sure that the multi-purpose buzzer operates.
- 2. Disengage the park brake.
- 3. Slowly push the accelerator pedal.

SLOW OR STOP THE VEHICLE

- 1. Release the accelerator pedal.
- 2. Push the brake pedal.

PARK THE VEHICLE

- 1. Stop the vehicle.
- 2. Engage the park brake to lock the wheels.
- 3. Set the Forward / Neutral / Reverse control (FNR) to N.
- 4. Turn the key to OFF.
- 5. Remove the key. Keep the key in a safe area.

DRIVING CONDITIONS

UNPAVED SURFACES

Precautions for operation on unpaved or unimproved surfaces:

- Decrease vehicle speed.
- Use extreme caution.

UPHILL SLOPE

🗥 WARNING

PREVENT STOPPING ON A HILL WHEN TOWING OR WITH A LOADED VEHICLE. IF A VEHICLE WITH A LOAD IS STOPPED ON A HILL, PREVENT SUDDEN STARTS, ROLLING BACKWARD, OR SUDDEN STOPS. FAILURE TO HEED THIS WARNING CAN CAUSE THE VEHICLE TO ROLL-OVER, POSSIBLY RESULTING IN SERIOUS PERSONAL INJURY.

DO NOT USE THE ACCELERATOR PEDAL TO HOLD THE VEHICLE POSITION ON A SLOPE. WHEN STOPPED ON A SLOPE, USE THE BRAKE PEDAL TO HOLD THE VEHICLE POSITION.

TO PREVENT ROLL-OVER, PROPERTY DAMAGE, AND PERSONAL INJURY, OPERATE THE VEHICLE SLOWLY ON A SLOPE.



TO HELP PREVENT ROLL-OVER, OPERATE THE VEHICLE SLOWLY STRAIGHT UP AND DOWN SLOPES. DO NOT OPERATE THE VEHICLE ON SLOPES THAT ARE MORE THAN A 20% INCLINE.

VEHICLE ROLLBACK WHEN STARTING ON AN INCLINE MAY CAUSE PROPERTY DAMAGE, SERIOUS INJURY, OR DEATH. USE THE BRAKE PEDAL TO HOLD THE VEHICLE UNTIL THE DRIVETRAIN IS FULLY ENGAGED.

Precautions when on an uphill slope:

- Prevent driving on slopes that exceed 20% grade.
- Always examine the terrain carefully before driving on a slope. Do not drive on a slope with slippery or loose surfaces.
- Keep your feet on the floorboard.
- Drive in a straight line on the slope.
- Prevent driving at an offset angle. An offset angle will cause the vehicle to lean sharply to one side.
- Continue at a stable rate of speed. Do not accelerate quickly.
- Do not stop a vehicle with a load on a slope. If a vehicle with a load must stop on a slope, prevent backwards movement or sudden starts or stops.
- Do not go over the top of a hill at high speed. Obstacles, sharp drop-offs, other vehicles, or persons could be on the other side of the hill.

SIDE HILL SLOPE

TO PREVENT ROLL-OVER, PROPERTY DAMAGE, AND PERSONAL INJURY, OPERATE THE VEHICLE SLOWLY ON A SLOPE.

VEHICLE ROLLBACK WHEN STARTING ON AN INCLINE MAY CAUSE PROPERTY DAMAGE, SERIOUS INJURY, OR DEATH. USE THE BRAKE PEDAL TO HOLD THE VEHICLE UNTIL THE DRIVETRAIN IS FULLY ENGAGED.

Vehicle operation on a side hill slope is not recommended.

Precautions if driving on a side hill slope is unavoidable:

- Prevent driving on slopes that exceed 10% grade.
- Decrease vehicle speed.
- Use extreme caution.
- Always examine the terrain carefully before driving on a slope. Do not drive on a slope with slippery or loose surfaces.
- Keep your feet on the floorboard.
- Continue at a stable rate of speed. Do not accelerate quickly.





DOWNHILL SLOPE

PREVENT STOPPING ON A HILL WHEN TOWING OR WITH A LOADED VEHICLE. IF A VEHICLE WITH A LOAD IS STOPPED ON A HILL, PREVENT SUDDEN STARTS, ROLLING BACKWARD, OR SUDDEN STOPS. FAILURE TO HEED THIS WARNING CAN CAUSE THE VEHICLE TO ROLL-OVER, POSSIBLY RESULTING IN SERIOUS PERSONAL INJURY.

TO PREVENT ROLL-OVER, PROPERTY DAMAGE, AND PERSONAL INJURY, OPERATE THE VEHICLE SLOWLY ON A SLOPE.

TO HELP PREVENT ROLL-OVER, OPERATE THE VEHICLE SLOWLY STRAIGHT UP AND DOWN SLOPES. DO NOT OPERATE THE VEHICLE ON SLOPES THAT ARE MORE THAN A 20% INCLINE.

USE THE BRAKE PEDAL TO CONTROL THE VEHICLE SPEED WHEN DRIVING DOWN A SLOPE.

THE OPERATOR MUST CONTROL THE VEHICLE SPEED WHEN GOING DOWN A SLOPE.

VEHICLE ROLLBACK WHEN STARTING ON AN INCLINE MAY CAUSE PROPERTY DAMAGE, SERIOUS INJURY, OR DEATH. USE THE BRAKE PEDAL TO HOLD THE VEHICLE UNTIL THE DRIVETRAIN IS FULLY ENGAGED.

Precautions when on a downhill slope:

- Prevent driving on slopes that exceed 20% grade.
- Always examine the terrain carefully before driving on a slope. Do not drive on a slope with slippery or loose surfaces.
- Keep the heavy end of the vehicle uphill.
- Keep your feet on the floorboard.
- Drive in a straight line on the slope.
- Prevent driving at an offset angle. An offset angle will cause the vehicle to lean sharply to one side.
- Continue at a stable rate of speed. Do not accelerate quickly.
- Decrease the vehicle speed.
- Push the brake pedal gradually to slow the vehicle.

OVER OBSTACLES

Driving over obstacles is not recommended and should be avoided.

Precautions if driving over obstacles is unavoidable:

- Always examine the terrain for obstacles before driving in a new area.
- Look forward and learn to read the terrain. Be constantly alert for hazards.
- Drive slowly and use caution when operating on unfamiliar terrain. Not all obstacles are immediately visible.
- Do not drive over large obstacles such as large rocks and fallen trees.

• Always have all passengers get out and move away from the vehicle before driving over an obstacle that could cause a roll over.

BELOW OBSTACLES

\land WARNING

DO NOT OPERATE THE VEHICLE BELOW OBJECTS WITH A HEIGHT THAT IS LESS THAN THE HEIGHT OF THE VEHICLE.

Driving below obstacles is not recommended.

Precautions if operation below obstacles is unavoidable:

- Always examine the terrain for obstacles before driving in a new area.
- Look forward and learn to read the terrain. Be constantly alert for low hanging obstacles such as tree limbs.
- Drive slowly and use caution when operating on unfamiliar terrain. Not all obstacles are immediately visible.

NIGHT TIME

🗥 DANGER

OPERATING THE VEHICLE AT NIGHT WITHOUT THE CORRECT EQUIPMENT CAN CAUSE PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH. TO OPERATE THE VEHICLE AT NIGHT, THE VEHICLE MUST HAVE HEADLIGHTS, TAILLIGHTS, AND REFLECTORS.

Vehicle operation at night is not recommended. When driving at night is unavoidable, the vehicle must have:

- Headlights
- Tail lights
- Reflectors

Precautions if driving at night is unavoidable:

- Always have headlights on.
- Always examine the terrain for obstacles before driving in a new area.
- Look forward and learn to read the terrain. Be constantly alert for hazards.
- Drive slowly and use caution when operating on unfamiliar terrain. Not all obstacles are immediately visible.

THROUGH WATER

🗥 WARNING

DRIVING THROUGH WATER CAN DECREASE BRAKE PERFORMANCE. AFTER DRIVING THROUGH WATER, LIGHTLY PUSH THE BRAKE PEDAL TO CHECK THE BRAKE PERFORMANCE. IF THE VEHICLE SPEED DOES NOT DECREASE AT A NORMAL RATE, CONTINUE TO PUSH THE BRAKE PEDAL UNTIL THE BRAKE PERFORMANCE IS BACK TO NORMAL.

Vehicle operation through water is not recommended and should be avoided.

Precautions when driving through water is unavoidable:


• Decrease the vehicle speed.





- Use extreme caution.
- Do not drive through water that is more than 3 inches (7.62 cm) high.

WITH CARGO



BEFORE A LOAD IS PUT IN THE VEHICLE, ENGAGE PARK BRAKE TO LOCK THE WHEELS.

THE CARGO IN THE VEHICLE CAN MOVE AND AFFECT THE HANDLING, STEERING, AND BRAKES. DO NOT HAVE TOP HEAVY LOADS. SECURE THE CARGO. REDUCE THE SPEED OF THE VEHICLE AND TURN SLOW.

A LOAD ON THE TAILGATE IN THE VERTICAL OR HORIZONTAL POSITION CAN CAUSE PROPERTY DAMAGE. DO NOT PUT A LOAD ON THE TAILGATE. CLOSE THE TAILGATE WHILE THE VEHICLE OPERATES.

Hauling cargo incorrectly can change the vehicles handling and may cause loss of control or brake instability, which can cause serious injury or death.

Precautions when operating with cargo:

- Always read and understand the load distribution warnings listed on the safety labels. The total load (operator, passenger, accessories, cargo and weight on hitch) must not exceed the maximum weight capacity of the vehicle. Do not exceed the published capacities.
- Do not exceed the maximum weight capacity of the vehicle. When determining added weight to the vehicle, include the weight of the operator, passenger, accessories, loads in the rack or box and the load on the trailer tongue. The combined weight of these items must not exceed the maximum weight capacity.
- Keep the heavy end of the vehicle uphill.
- Always load the cargo box with the load as far forward and as low as possible.
- Always operate the vehicle with extreme caution when hauling or towing loads.
- Secure all loads before operating. Unsecured loads can cause unstable operating conditions, which could cause loss of vehicle control.
- Operate only with stable and safely arranged loads. When handling off-centered loads that cannot be centered, correctly fasten the load and operate with extra caution. Always attach the tow load to the hitch point designated for the vehicle.
- Heavy loads can cause braking and control problems. Use extreme caution when applying brakes with a loaded vehicle. Avoid terrain or situations that may require backing downhill. Use extreme caution when operating with loads that extend over the rack sides.
- Stability and maneuverability may be adversely affected, causing a roll over.
- Slow down and drive in the lowest gear available.
- Decrease speed and allow a greater distance for breaking when hauling cargo.
- When operating over rough or hilly terrain, decrease speed and cargo to maintain stable driving conditions.
- Do not move faster than the recommended speeds. Vehicle should never exceed 10 mph (16 km/h) while towing a load on a level grass surface. Vehicle speed should never exceed 5 mph (8



km/h) when towing loads in rough terrain, while cornering, or while climbing or going down a hill.





(Page intentionally left blank.)



VEHICLE MAINTENANCE



ANGER	INCORRECT OPERATION OF THE CARGO BED CAN CAUSE PERSONAL INJURY OR DEATH. KEEP ALL PERSONS CLEAR OF THE CARGO BED AREA WHEN THE CARGO BED IS LIFTED, LOWERED, OR DURING MAINTENANCE. KEEP HANDS CLEAR OF ALL CRUSH AREAS. DO NOT LET THE CARGO BED FALL. BEFORE THE CARGO BED IS LIFTED, REMOVE ALL CARGO AND ACCESSORIES FROM THE CARGO BED. CORRECTLY ENGAGE THE PROP ROD. CAREFULLY LOWER THE CARGO BED. A WHEEL OR TIRE THAT HAS DAMAGE CAN CAUSE PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH. DO NOT TRY TO REPAIR
	A WHEEL OR TIRE. SPEAK WITH YOUR LOCAL DEALER OR DISTRIBUTOR FOR REPAIRS.
	UNINTENDED VEHICLE OPERATION CAN CAUSE SERIOUS PERSONAL INJURY OR DEATH. BEFORE LEAVING OR VEHICLE MAINTENANCE, DISABLE THE VEHICLE.
	ONLY TRAINED TECHNICIANS SHOULD SERVICE OR REPAIR THE VEHICLE. ANYONE DOING EVEN SIMPLE REPAIRS OR SERVICE SHOULD HAVE KNOWLEDGE AND EXPERIENCE IN ELECTRICAL AND MECHANICAL REPAIR. THE APPROPRIATE INSTRUCTIONS MUST BE USED WHEN PERFORMING MAINTENANCE, SERVICE, OR ACCESSORY INSTALLATION.
	FAILURE TO CORRECTLY MAINTAIN THE VEHICLE CAN CAUSE DECREASED VEHICLE PERFORMANCE, SERIOUS PERSONAL INJURY, OR DEATH.
	FAILURE TO MAKE NECESSARY REPAIRS CAN CAUSE A FIRE, PROPERTY DAMAGE, SERIOUS PERSONAL INJURY, OR DEATH. IF PROBLEMS ARE FOUND DURING SCHEDULED INSPECTION OR SERVICE, OPERATE THE VEHICLE ONLY WHEN REPAIRS ARE MADE.
	UNINTENTIONAL VEHICLE STARTUP CAN CAUSE PERSONAL INJURY, PROPERTY DAMAGE, OR A FIRE. SET THE RUN/TOW SWITCH TO TOW. DISCONNECT THE BATTERIES. WAIT 90 SECONDS FOR THE CONTROLLER DISCHARGE.
	DO NOT WORK ON THE VEHICLE POWERTRAIN WHEN THE VEHICLE IS LOADED.
	DO NOT WEAR LOOSE CLOTHING OR JEWELRY SUCH AS RINGS, WATCHES, CHAINS, ETC., WHEN SERVICING THE VEHICLE.
	DO NOT WEAR LOOSE CLOTHING OR JEWELRY SUCH AS RINGS, WATCHES, CHAINS, ETC., WHEN SERVICING THE VEHICLE OR BATTERY CHARGER.
	DO NOT WORK ON VEHICLE POWERTRAIN OR UNDER THE CARGO BED WHEN IT IS LOADED.
	LIFT ONLY ONE END OF THE VEHICLE AT A TIME. USE A SUITABLE LIFTING DEVICE WITH 1000 LB (454 KG) MINIMUM LIFTING CAPACITY. DO NOT USE THE LIFTING DEVICE TO HOLD THE VEHICLE IN THE LIFTED POSITION. USE APPROVED JACK STANDS OF PROPER WEIGHT CAPACITY TO SUPPORT THE VEHICLE AND CHOCK THE WHEELS THAT REMAIN ON THE FLOOR.

IF WIRES ARE REMOVED OR REPLACED, MAKE SURE THAT THE WIRING AND WIRE HARNESS ARE CORRECTLY ROUTED AND ATTACHED. FAILURE TO CORRECTLY ROUTE AND ATTACH THE WIRING COULD RESULT IN VEHICLE MALFUNCTION, PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH.

▲ CAUTION

WEAR SAFETY GLASSES OR APPROVED EYE PROTECTION WHEN YOU DO THE SERVICING OF THE VEHICLE. WEAR A FULL FACE SHIELD AND RUBBER GLOVES WHEN NEAR BATTERIES.

DISABLE THE VEHICLE

<u> WARNING</u>

UNINTENDED VEHICLE OPERATION CAN CAUSE SERIOUS PERSONAL INJURY OR DEATH. BEFORE LEAVING OR VEHICLE MAINTENANCE, DISABLE THE VEHICLE.

- 1. Park the vehicle on a solid level surface.
- 2. Engage the park brake to lock the wheels.
- 3. Turn the key to OFF.
- 4. Remove the key.
- 5. Set the Forward / Neutral / Reverse control (FNR) to N.
- 6. Put the chocks against the wheels.

VEHICLE CLEANING

CLEANING THE WINDSHIELD

Use a soft towel and water to clean the windshield. Use mild soap as necessary. Do not use a household window cleaner.

CLEANING THE VEHICLE EXTERIOR

NOTICE

MOISTURE WILL CAUSE ELECTRICAL COMPONENT DAMAGE. DO NOT USE A PRESSURE WASHER OR STEAM CLEANER TO CLEAN THE VEHICLE.

Use only commercially available automotive cleaners with a sponge or soft cloth for normal cleaning. A garden hose at normal residential water pressure is sufficient.

Use a commercially available aluminum cleaner paste and fine grade (No. 00) steel wool to remove oxidation or discoloration from aluminum.

Use non-abrasive wax products. Battery acid, fertilizers, tars, asphalt, creosote, paint, or chewing gum should be removed immediately to prevent possible stains.

Discard the waste water correctly.





CLEANING THE VEHICLE INTERIOR

NOTICE

MOISTURE WILL CAUSE ELECTRICAL COMPONENT DAMAGE. DO NOT USE A PRESSURE WASHER OR STEAM CLEANER TO CLEAN THE VEHICLE.

The seats of the vehicle will last longer with proper cleaning. Use a solution of 10% liquid soap and warm water applied with a soft cloth. Use a soft bristle brush to remove imbedded dirt.

Discard the waste water correctly.

MAINTENANCE SCHEDULE

MAINTENANCE SCHEDULE OVERVIEW

A preventive maintenance program with regular maintenance can prevent excessive vehicle downtime and repair costs. Use these items to keep the vehicle in proper working condition.

- Daily Pre-Operation Safety Checklist
- Vehicle Performance Inspection
- Maintenance Service Schedule

If a vehicle is found to be in bad operational condition, remove it from operation. Removal from operation will prevent more damage to the vehicle and prevent the possible injury because of dangerous conditions.

Speak with your dealer or distributor for maintenance and repairs.

MAINTENANCE SERVICE SCHEDULE

Note: The Maintenance Service Schedule must be done more frequently on vehicles that are constantly subjected to heavy use or severe operating conditions.

INTERVAL	DESCRIPTION
Initial: 6 weeks	Single Point Watering System (SPWS): Establish a watering interval.
	SPWS: Make sure the valves operate correctly. Examine the battery acid level of all the batteries. Add water if necessary.
Daily	Do the Daily Pre-Operational Safety Check.
	Do the Daily Vehicle Performance Inspection.
	Charge the batteries.
Weekly	No SPWS: Examine the battery acid level of all the batteries. Add water as necessary.



Page 68

INTERVAL	DESCRIPTION
	Examine the tire pressure.
	Clean the vehicle.
Monthly	SPWS: Add water to the batteries.
	Clean the batteries.
	Clean the battery compartment.
	Make sure the battery cables are tight.
	Make sure the battery hold-downs are tight.
Quartarly	Do an inspection of the deionizer.
Quarterly	Do an inspection of the SPWS.
	Use WD-40 [®] to lubricate the battery charger receptacle.
	Have a trained technician:
	 examine and lubricate the brake system
50 hours / 6 months	examine the electrical system
	examine the front wheel alignment
	lubricate the front suspension
	• examine the Motor Controller Output Regulator (MCOR)
	lubricate the accelerator pedal
	Have a trained technician examine the:
100 hours / 12 months	batteries
	front wheel bearings
	pedal components
	safety decals
	transaxle fluid



LIFT THE VEHICLE

8

LIFT THE FRONT OF THE VEHICLE


🗥 WARNING

LIFTING THE VEHICLE WITH CARGO CAN CAUSE PROPERTY DAMAGE, SERIOUS PERSONAL INJURY, OR DEATH. REMOVE ALL CARGO FROM THE CARGO BED BEFORE THE VEHICLE IS LIFTED.

Before the vehicle is lifted:

- Disable the vehicle.
- Disconnect the batteries.
- Use a jack and jack stands rated for the vehicle.

To lift the front of the vehicle:



- 1. Place the jack in the center of the lift point.
- 2. Lift the front of the vehicle.
- 3. Put jack stands under the frame rails.
- 4. Lower the vehicle onto the jack stands.

LIFT THE REAR OF THE VEHICLE


MARNING

LIFTING THE VEHICLE WITH CARGO CAN CAUSE PROPERTY DAMAGE, SERIOUS PERSONAL INJURY, OR DEATH. REMOVE ALL CARGO FROM THE CARGO BED BEFORE THE VEHICLE IS LIFTED.

Before the vehicle is lifted:

- Disable the vehicle.
- Disconnect the batteries.
- Use a jack and jack stands rated for the vehicle.

To lift the rear of the vehicle:



- 1. Place the jack in the center of the lift point.
- 2. Lift the rear of the vehicle.
- 3. Put jack stands under the frame rails.
- 4. Lower the vehicle onto the jack stands.

LOWER THE VEHICLE

LOWER THE FRONT OF THE VEHICLE

Before the front of the vehicle is lowered:


• Use a jack rated for the vehicle.





To lower the front of the vehicle:

8



- 1. Place the jack in the center of the lift point.
- 2. Lift the vehicle off of the jack stands.
- 3. Remove the jack stands.
- 4. Lower the vehicle.


LOWER THE REAR OF THE VEHICLE

Before the rear of the vehicle is lowered:

• Use a jack rated for the vehicle.



To lower the rear of the vehicle:



- 1. Place the jack in the center of the lift point.
- 2. Lift the vehicle off of the jack stands.
- 3. Remove the jack stands.
- 4. Lower the vehicle.

TIRE PRESSURE MEASUREMENT

Before the tire pressure measurement:

• Disable the vehicle.

To measure the tire pressure:

- 1. Remove the valve stem cap.
- 2. Use a pressure gauge to measure the tire pressure.
- 3. Adjust to meet the recommended tire pressure.
 - *Note:* Go to the approved wheel and tire assemblies matrix on http://www.clubcar.com for information regarding tire type, inflation pressure, and lug nut torque.
- 4. Install the valve stem cap.

WHEEL ASSEMBLY

WHEEL ASSEMBLY REMOVAL

Before the wheel assembly is removed:

Page 73



• Disable the vehicle.

To remove the wheel assembly:

- 1. Remove the wheel cover.
- 2. Loosen the lug nuts.
- 3. Lift the vehicle to allow for removal of the wheel assembly.
- 4. Remove the lug nuts.
- 5. Remove the wheel assembly.

WHEEL ASSEMBLY INSTALLATION

Before wheel assembly installation:

• Disable the vehicle.

To install the wheel assembly:

- 1. Lift the vehicle to allow for installation of the wheel assembly.
- 2. Align the wheel assembly onto the hub of the vehicle.

Note: Make sure that the valve stem points to the outer side of the vehicle.

Note: Make sure that the tire tread is in the correct direction of travel.


- Tighten the lug nuts until they are hand-tight. 3.
- 4. Lower the vehicle.
- 5. Tighten the lug nuts to the recommended torque specification.

Note: Go to the approved wheel and tire assemblies matrix on http://www.clubcar.com for information regarding tire type, inflation pressure, and lugnut torque.

6. Install the wheel cover.

CARRYALL 300 ELECTRIC

Operators Manual



BATTERY MAINTENANCE





A CAUTION

9

WATER MAY BOIL OVER AND LEAK BATTERY ACID AND CAUSE PERSONAL INJURY OR PROPERTY DAMAGE. CHARGE THE BATTERIES BEFORE WATER IS ADDED.

LEAD-ACID BATTERIES CONTAIN DANGEROUS MATERIALS THAT CAN CONTAMINATE THE WATER AND SOIL, CAUSE ENVIRONMENTAL DAMAGE, CAUSE PROPERTY DAMAGE, AND PERSONAL INJURY. DO NOT ADD TOO MUCH WATER TO THE BATTERIES.

WEAR SAFETY GLASSES OR APPROVED EYE PROTECTION WHEN YOU DO THE SERVICING OF THE VEHICLE. WEAR A FULL FACE SHIELD AND RUBBER GLOVES WHEN NEAR BATTERIES.

BATTERY CLEANING

- 1. Apply an approved battery cleaner spray or water solution to the battery top and terminals. *Note:* The water solution is 1 cup (237 ml) baking soda for each 1 gallon (3.8 l) water.
- 2. Use a soft bristle brush to clean the battery top and terminals. Remove all corrosion.
- 3. Use tap water to clean the solution from the batteries. Correctly discard the waste water.
- 4. If the battery cable has corrosion, have a trained technician replace the battery cable.
- 5. Make sure the battery cables are tight. If a battery cable is not tight, tighten the hardware to 110 $lb \cdot in (12.4 \text{ N} \cdot m)$.
- 6. Let the terminals dry.
- 7. Apply battery terminal protector spray to the terminals.

BATTERY CHARGING

CHARGING WITH EXTERNAL CHARGER

🗥 DANGER

CHARGING BATTERIES EMIT HYDROGEN GAS, THAT IS EXPLOSIVE ABOVE 2% AIR CONCENTRATION. CHARGE THE BATTERIES IN A VENTILATED AREA WITHOUT COVERS OR ENCLOSURES.

CHARGING BATTERIES EMIT HYDROGEN GAS, THAT IS EXPLOSIVE ABOVE 2% AIR CONCENTRATION. KEEP BATTERIES AWAY FROM SPARKS AND OPEN FLAMES.

CHARGING BATTERIES EMIT HYDROGEN. HYDROGEN BECOMES AN EXPLOSIVE GAS AT 2% AIR CONCENTRATION. INDIVIDUAL VEHICLES REQUIRE ONE AIR EXCHANGE PER HOUR. FLEET 5 TIMES PER HOUR. THE TOTAL VOLUME OF AIR IN THE CHARGING AREA MUST BE CHANGED AT LEAST FIVE TIMES PER HOUR. EXHAUST FANS MUST BE LOCATED AT THE HIGHEST POINT OF THE ROOF. SPEAK WITH A LOCAL HVAC ENGINEER.

CHARGING THE BATTERIES WITH ACCESSORIES ON CAN CAUSE A FIRE AND PERSONAL INJURY. TURN OFF ALL ACCESSORIES BEFORE CHARGING THE BATTERIES.

Page 76

CARRYALL 300 ELECTRIC Operators Manual TPCC01MF00EN019 (Edition A) 🗥 WARNING

THE BATTERY CHARGER BECOMES HOT WHEN IT IS ON AND CAN CAUSE A FIRE, PROPERTY DAMAGE, OR PERSONAL INJURY. DO NOT COVER THE BATTERY CHARGER. DO NOT TOUCH. MAKE SURE THAT THE BATTERY CHARGER HAS ADEQUATE AIRFLOW. USE THE HANDLE. KEEP THE BATTERY CHARGER AWAY FROM CLOTHING AND FLAMMABLE MATERIAL.

LOOSE CORD CONNECTIONS CAN CAUSE A FIRE. MAKE SURE THAT ALL CORD CONNECTIONS AT THE RECEPTACLE ARE CLEAN AND TIGHT.

- 1. Turn the key to OFF.
- 2. Turn off all accessories.
- 3. Connect the AC cord to the charger.
- 4. Connect the AC cord to the power source.


NOTICE

INCORRECT REMOVAL AND INSTALLATION OF THE DC CORD CAN CAUSE DC CORD DAMAGE AND VEHICLE CHARGER RECEPTACLE DAMAGE. DO NOT TWIST, BEND, OR MOVE THE DC CORD PLUG SIDE TO SIDE. DO NOT PULL ON THE DC CORD. HOLD THE PLUG HANDLE AND PUSH THE PLUG STRAIGHT INTO THE VEHICLE CHARGER RECEPTACLE.

5. Connect the DC cord to the vehicle charger receptacle (1).

Note: The vehicle will start to charge in 2 to 10 seconds.

The charge indicator light will flash and the multi-purpose buzzer will operate when the vehicle starts to charge.




🛕 DANGER

IF THE DC CORD IS REMOVED TOO FAST, ARCING AND BURNING CAN CAUSE DAMAGE TO THE PLUG, RECEPTACLE, AND CAUSE THE BATTERIES TO EXPLODE. REMOVE THE DC CORD SLOW.

6. Before vehicle operation, disconnect the DC cord from the vehicle charger receptacle.




CHARGING WITH ONBOARD CHARGER



- 1. Turn the key to OFF.
- 2. Turn off all accessories.
- 3. Connect the AC cord (1) to the power source.

Note: The vehicle will start to charge in 2 to 10 seconds.

The charge indicator light will flash and the multi-purpose buzzer will operate when the vehicle starts to charge.



- 4. Before vehicle operation:
 - 4.A Disconnect the AC cord from the power source.
 - 4.B Retract the AC cord.

BATTERY ELECTRICAL CONNECTION

DISCONNECT THE BATTERIES

Before the batteries are disconnected:


• Disable the vehicle.

To disconnect the batteries:

DANGER

BATTERIES DISCONNECTED OR CONNECTED WITH THE RUN/ TOW SWITCH SET TO RUN CAN CAUSE A BATTERY EXPLOSION AND SERIOUS PERSONAL INJURY. SET THE RUN/TOW SWITCH TO TOW BEFORE THE BATTERIES ARE DISCONNECTED OR CONNECTED.

- 1. Set the Run/Tow switch to TOW.
- 2. Disconnect the negative (-) cable (1).



Disconnect the positive (+) cable (2).
 Note: Wait 90 seconds for the controller capacitors to discharge.

CONNECT THE BATTERIES

\land DANGER


BATTERIES DISCONNECTED OR CONNECTED WITH THE RUN/ TOW SWITCH SET TO RUN CAN CAUSE A BATTERY EXPLOSION AND SERIOUS PERSONAL INJURY. SET THE RUN/TOW SWITCH TO TOW BEFORE THE BATTERIES ARE DISCONNECTED OR CONNECTED.

1. Set the Run/Tow switch to TOW.





2. Connect the positive (+) cable (2).



- 3. Connect the negative (-) cable (1).
- 4. Tighten the hardware to 110 lb·in (12.4 N·m).
- 5. Apply battery terminal protector spray to the battery terminals.
- 6. Set the Run/Tow switch to RUN.

BATTERY HOLD-DOWN

Each hold-down must be tight to prevent the battery movement while the vehicle is in operation. Do not tighten too much or the battery case can crack or buckle.

1. Tighten the hold-down nuts to 110 lb·in (12.4 N·m).

ADD WATER TO A BATTERY WITHOUT SINGLE POINT WATERING SYSTEM


This information is for batteries without a Single Point Watering System (SPWS).


Before water is added:

• Disable the vehicle.

To add water to the batteries:

1. Unlock and remove the cap (1).





- 2. Make sure that the battery acid (2) is level with or above the top of the plates (3).
- 3. If the battery acid is level with or above the top of the plates:
 - 3.A Install and lock the cap.
 - 3.B Fully charge the batteries.
- 4. If the battery acid is below the top of the plates:
 - 4.A Add water until the battery acid is level with the top of the plates.
 - 4.B Install and lock the cap.
 - 4.C Fully charge the batteries.
- 5. Unlock and remove the cap.
- 6. Make sure that the battery acid is 0.5 inches (13 mm) above the top of the plates. Add water as necessary.

A CAUTION

LOOSE BATTERY CAPS CAN CAUSE BATTERY ACID TO LEAK. FULLY ATTACH THE BATTERY CAPS TO PREVENT LEAKAGE.

7. Install and lock the cap.



DEIONIZER

NOTICE

FREEZING TEMPERATURES WILL CAUSE DAMAGE TO WATER SUPPLY COMPONENTS. DRAIN ALL WATER SUPPLY COMPONENTS. STORE WATER SUPPLY COMPONENTS IN AN EMPTY STATE.

Refer to the deionizer operator and maintenance manual for maintenance and operator information.

ADD WATER TO BATTERIES WITH SINGLE POINT WATERING SYSTEM

▲ CAUTION

LEAD-ACID BATTERIES CONTAIN DANGEROUS MATERIALS THAT CAN CONTAMINATE THE WATER AND SOIL, CAUSE ENVIRONMENTAL DAMAGE, AND PERSONAL INJURY. IF BATTERY ACID LEAKS FROM THE BATTERIES, STOP THE FILL PROCESS. DISCONNECT THE PRESSURE REGULATOR FROM THE BATTERY FILL COUPLING. SPEAK WITH YOUR DEALER OR DISTRIBUTOR.

1. Add water to the batteries. Refer to the hand pump or deionizer operator and maintenance manual.

WATERING INTERVALS

The watering intervals are affected by:

- Age of the batteries
- Application
- Charging methods
- Local climate

Examine the consumption rates manually. Examine new batteries monthly until consumption rates are known. Examine used batteries weekly until consumption rates are known. The watering interval must maintain the electrolyte level above the top of the plates.

During periods of heavy use, water the batteries no more than one time a week. During periods of light use, water the batteries no more than one time a month. Only add water to a warm battery that is fully charged. Do not add water to the batteries before charging.

WATER QUALITY

OVERVIEW

Water purity is one of the more important factor in the performance and life span of the vehicle batteries. Club Car has put an increased importance on water purity and battery maintenance. Club Car recommends the use of distilled water or a deionizer because of the cost of water testing and fluctuations in the daily changes to water quality.



PREFERRED SOURCES

DEIONIZED WATER

Deionized water is water that has all charged mineral ions removed (example: sodium, calcium, iron, copper, and chloride).

Obey the manufacturers' recommendation for filter replacement. A clean filter will make sure that the deionized water quality stays high.

DISTILLED WATER

Distilled water is the most common type of water used in batteries. Distilled water is made by boiling water, collecting the steam from the boiling, and allowing the steam to condense back into water. The distilling process results in a water source which is free of minerals that can lead to the degradation of battery performance and life.

ALTERNATE SOURCES

REVERSE OSMOSIS

Reverse osmosis involves the movement of water through a membrane that lets water pass while trapping solids. The selection of membranes and usage frequency determines the quantity of solids or impurities which get caught and hence the purity quality of the filtered water. Because of the variance in water quality consistency, Club Car recommends the use of the deionizer or distilled water.

TAP WATER

Because of the levels of dissolved minerals and chemicals that can degrade battery performance and life the use of tap water without filtering should be limited. Regular water analyses must be done to check for impurities if unfiltered tap water is used.

WATER IMPURITY

Listed are the maximum permitted water soluble minerals, solids, and contaminates in parts per million and their impact on battery performance.

IMPURITY	PERMITTED CONTENT (PARTS PER MILLION)	IMPURITY EFFECTS
Ammonia	8.0	Slight self-discharge of both plates
Antimony	5.0	Self-discharge, decreases life, and lower on-charge voltage
Arsenic	0.5	Self-discharge and can form poisonous gas
Calcium	40.0	Increase of positive plate shedding
Chloride	5.0	Loss of capacity in plates and greater loss in positive plates
Copper	5.0	Increased self-discharge and lower on-charge voltage



IMPURITY	PERMITTED CONTENT (PARTS PER MILLION)	IMPURITY EFFECTS
Iron	3.0	Increased self-discharge and lower on-charge voltage
Magnesium	40.0	Decreased life
Nickel	None allowed	Intense lowering of on-charge voltage
Nitrates	10.0	Increased sulfation of negative plate
Nitrites	5.0	Plate corrosion, loss of capacity, and decreased life
Platinum	None allowed	Violent self-discharge and lower on-charge voltage
Selenium	2.0	Positive plate shedding
Zinc	4.0	Slight self-discharge of negative plates
Organic and volatile matter	50.0	Corrosion of positive plates
Suspended matter	Trace	None
Total solids	100.0	None





TRANSPORT AND TOW





A DANGER	NEVER ALLOW PASSENGERS TO RIDE IN THE VEHICLE OR TRAILER BEING TOWED. DO NOT LET PASSENGERS RIDE IN THE VEHICLE OR TRAILER BEING TOWED.
	KEEP AWAY FROM THE AREA BETWEEN THE TOW VEHICLE AND THE TOWED VEHICLE OR TRAILER.
	DO NOT TOW A CLUB CAR VEHICLE BEHIND A PASSENGER VEHICLE OR TRUCK ON A PUBLIC ROAD. ONLY TOW A CLUB CAR VEHICLE ON AN APPROVED TRAILER.
AUTION	USE EXTREME CAUTION WHEN TOWING. DO NOT MAKE SHARP TURNS WITH A TRAILER. DO NOT TOW A VEHICLE OR TRAILER ON PUBLIC ROADS OR HIGHWAYS. DECREASE THE VEHICLE SPEED WHEN TOWING A VEHICLE OR TRAILER.
	THE VEHICLE CAN FALL OFF THE TRAILER AND CAUSE PROPERTY DAMAGE AND PERSONAL INJURY. MAKE SURE THE VEHICLE IS CORRECTLY SECURED TO THE TRAILER.
	DO NOT PUT THE VEHICLE ON A TRAILER WITH A LOAD IN THE VEHICLE CARGO BED.
	BEFORE TRANSPORTING THE VEHICLE ON A TRAILER, REMOVE THE WINDSHIELD. SECURE THE SEAT BOTTOM.
	WHEN A TRAILER IS USED ON A PUBLIC ROAD, THE TRAILER MUST MEET ALL FEDERAL, STATE, AND LOCAL REQUIREMENTS SUCH AS TAILLIGHTS AND BRAKE LIGHTS.

PREPARE THE VEHICLE TO BE TOWED

- 1. Turn the key to OFF.
- 2. Remove the key. Keep the key in a safe area.
- 3. Set the Forward / Neutral / Reverse control (FNR) to N.
- 4. Set the Run/Tow switch to TOW.

TOW WITH THE VEHICLE

- The vehicle can tow one vehicle that is the same size.
- Use only a Club Car approved tow kit.
- 1. Prepare the vehicle to be towed.
- 2. Use a Club Car approved tow kit to tow the vehicle.
- 3. Tow the vehicle under 5 mph (8 kmh).

VEHICLE TRANSPORT PREPARATION

The vehicle is not designed to be towed at speeds over 5 mph. If movement over long distances or on public roads is necessary, transport the vehicle on a trailer. Use a trailer that has a load rating of more than the weight of the vehicle.

Club Car Page 86

- 1. Set the park brake.
- 2. Set the Forward / Neutral / Reverse control (FNR) to N.
- 3. Turn the key to OFF.
- 4. Remove the key. Keep the key in a safe area.
- 5. Remove all cargo from the vehicle.
- 6. Remove the windshield from the vehicle.
- 7. Secure all doors, access panels, seat bottoms, and windshield.
- 8. Examine the vehicle for loose parts. Tighten as necessary.
- 9. Secure the vehicle to the trailer.

VEHICLE TRANSPORT RECOVERY

- 1. Make sure that the trailer is correctly configured to remove the vehicle from the trailer safely.
- 2. Remove all materials used to secure the vehicle to the trailer.
- 3. Examine the vehicle for loose parts. Tighten as necessary.
- 4. Install the windshield.






(Page intentionally left blank.)





EXTENDED STORAGE







FROZEN BATTERY ACID CAN CAUSE DAMAGE INCLUDING LEAKS AND EXPLOSIONS. IF THE BATTERY ACID FREEZES, REPLACE THE BATTERY BEFORE CHARGING OR USE. BATTERIES IN A LOW STATE OF CHARGE WILL FREEZE AT LOW TEMPERATURES. KEEP THE BATTERIES IN A HIGH STATE OF CHARGE.

UNINTENDED VEHICLE OPERATION CAN CAUSE SERIOUS PERSONAL INJURY OR DEATH. BEFORE LEAVING OR VEHICLE MAINTENANCE, DISABLE THE VEHICLE.

EXTENDED STORAGE PREPARATION

Keep sufficient water levels in each battery cell for a minimum of two weeks before extended storage to make sure proper mixing of water and battery acid. If necessary, add water as necessary then correctly charge batteries.

Note: It takes approximately five charge cycles with a minimum of 10-amp hours of use after each charge to correctly mix the water with battery acid.

To prepare your vehicle for extended storage:

- 1. Turn off all electronic accessories.
- 2. Set the Forward / Neutral / Reverse control (FNR) to N.
- 3. Turn the key to OFF.
- 4. Remove the key. Keep the key in a safe area.
- 5. Put chocks against the wheels.
 - *Note:* Do not engage the park brake.
- 6. Remove all cargo and personal items.
- 7. Run/Tow switch position:
 - *Note:* The charge indicator light is disabled when the Run/Tow switch is set to TOW.
 - 7.A <u>On vehicles equipped with Visage that will have remote monitoring</u>, set the Run/Tow switch to RUN.
 - 7.B <u>On vehicles equipped with Visage that will not have remote monitoring</u>, set the Run/Tow switch to TOW.
 - 7.C *On all other vehicles,* set the Run/Tow switch to TOW.
- 8. Clean the batteries.
- 9. Tighten all battery cable connections to 110 lb·in (12.4 N·m).
- 10. Keep the vehicle in a cool and dry area to keep battery self-discharge to a minimum.
- 11. Adjust pressure in each tire to recommended tire pressure.
- 12. Clean the vehicle.





- 13. <u>If one or more conditions shown cannot be done while in storage</u>, disconnect the negative (-) battery cable. Make sure that the negative (-) battery cable does not touch the battery terminal.
 - The battery charger must stay connected to an electric outlet
 - AC electrical power will be available during storage
 - Battery acid levels will be kept at a sufficient level while in storage
- 14. If all conditions shown can be done while in storage, do as follows:
 - The battery charger must stay connected to an electric outlet
 - AC electrical power will be available during storage
 - Battery battery acid levels will be kept at a sufficient level while in storage
 - 14.A Connect the battery charger to the vehicle. Keep battery chargers connected during storage. The charger will automatically connect when necessary.
 - 14.B Examine the battery acid level and charger function monthly.
 - *Note:* The charger is operating correctly when the blue light is on and the triangular light is off.

RETURN TO SERVICE FROM EXTENDED STORAGE

- 1. Clean the batteries.
- 2. If the batteries were disconnected, connect the batteries.
- 3. Fully charge the batteries.
- 4. Set the Run/Tow switch to RUN.
- 5. Set the Forward / Neutral / Reverse control (FNR) to N.
- 6. Adjust the pressure in each tire to the recommended tire pressure.
- 7. Have a trained technician lubricate the vehicle.
- 8. Do a daily pre-operation safety checklist.
- 9. Do a vehicle performance inspection.





(Page intentionally left blank.)





WARRANTIES





LIMITED WARRANTY

WARRANTY

Club Car, LLC ("Club Car") hereby warrants to the Original Purchaser or Lessee, as those terms are defined herein, and subject to the provisions, limitations and exclusions in this limited warranty, that its new vehicle or new component purchased from Club Car or an Authorized Dealer or Distributor shall be free from defects in material and workmanship under normal use and service for the periods stated below, subject to the provisions, limitations and exclusions in this limited warranty.

This limited warranty covers material, workmanship and repair labor cost as to those items specifically listed below for the periods specified. Such repair labor shall be performed only by Club Car, its Authorized Dealers or Distributors, or a service agency approved by Club Car. For repairs made by qualified technicians other than Club Car's factory technicians or an Authorized Dealer or Distributor, Club Car will provide only the replacement parts or components.

If the warranty registration form is not completed and returned to Club Car at the time of the original retail sale, the Purchaser must provide proof of date of purchase with any warranty claim.

ITEM	SUB-ITEMS	COVERAGE
VEHICLE MAINFRAME	Not applicable	2 years or 2,000 hours
SUSPENSION	Steering gearbox, steering column, shocks, and leaf springs	2 years or 2,000 hours
ELECTRIC POWERTRAIN	Electric motor, transaxle, and MCOR	3 years or 2,000 hours
DEEP CYCLE BATTERY	6-volt standard	4 years or 18,000 hours
	6-volt heavy duty	4 years or 23,000 hours
	8-volt	4 years or 16,000 hours
MAJOR ELECTRONICS	Solid state speed controller and battery charger	4 years or 16,000 hours
PEDAL GROUP	Pedal group mechanical assembly, brake cluster assemblies, and brake cables	2 years or 2,000 hours
SEATS	Seat bottom, seat back, and armrests	2 years or 2,000 hours
CANOPY SYSTEM	Canopy, rear canopy supports, drainage system, and structural accessory module (SAM)	2 years or 2,000 hours

WARRANTY TIMEFRAME

CAB ASSEMBLY	Cab Assembly and Doors (if equipped)	2 years or 2,000 hours
BODY GROUP	Body and dash panels	2 years or 2,000 hours
ALL REMAINING COMPONENTS	Solenoid, limit switches, voltage regulator, F&R switch, and options and accessories supplied by , including components not specified otherwise	2 years or 2,000 hours

EXCLUSIONS

Excluded from any Club Car warranty is damage to a vehicle or component resulting from a cause other than a defect including poor maintenance, neglect, abuse, accident and collision, maintenance adjustments, unreasonable or unintended strain or use, improper installation of accessories, installation of parts or accessories that are not original equipment including Club Car approved or nonapproved GPS systems, non-approved alteration, and acts of God. Also excluded from any Club Car warranty are all fuses, filters, decals (except safety decals), lubricants, routine wear items such as engine mounts, bed floor lining, mats, pads, spark plugs, light bulbs, brake pads, belts, brushes, solenoids, bushings, drive buttons, cosmetic deterioration, and items that deteriorate, fade or fail due to exposure or ordinary wear and tear.

The provisions of this limited warranty shall not apply to failure due to the following conditions:

- Batteries
 - Improper charging of a vehicle due to the use of a battery charger model not approved by Club Car for use with the vehicle.
 - Use of water in batteries, including tap water, that contains impurities. Distilled water or a
 properly maintained, Club Car approved battery water deionizer and filter system must be
 used to ensure water quality.
 - Abuse such as overcharging, undercharging, improper fluid levels, loose wiring and fasteners, or rusted or corroded hardware.
 - Use of energy management systems that do not allow a minimum of 12 hours of charge time to assure proper charging.
 - Use of any accessories that do not draw power off the complete system voltage.
 - Neglect, breakage, freezing, fire, explosion, wreckage, melted terminal posts, the addition of any chemical, or the operation of the battery in an uncharged condition (below half charge 1.200 specific gravity); the installation of the batteries in reverse or recharging in reverse, breakage of containers, covers, or terminal post, or batteries used in applications for which they were not designed.
 - A battery damaged by a defective charger or batteries in vehicles that do not receive proper charging.
 - A vehicle not having an operational charger on a circuit that has the parameters specified in the vehicle owner's manual (the number of operational chargers must equal the number of operational vehicles), or use of an unapproved algorithm.
- Lack of proper maintenance such as preventive maintenance checks, proper rotation of vehicles in a fleet application, maintaining proper tire pressure and alignment and tightening loose wire connections as outlined in the owner's manual.
- Damages caused by improper installation of the component.





- Failed semiconductor parts such diodes and fuses that are vulnerable to electrical overloads (including lightning) beyond the control of CLUB CAR.
- Damaged charger AC and DC cord set with plug, which is a wear item and subject to user abuse.
- Use of gasoline containing more than 10 percent ethanol.

Without limiting the generality of the foregoing in any way, and as part of its limited warranty exclusion, Club Car does not warrant that its vehicle or components such as batteries, computer, controller or electrical device are suitable for use in any application other than in its products. As in the use of any vehicle, batteries, computer, controller or electrical device, a prudent owner will read and study the owner's manual, the operator instructions and the warning labels; and will exercise due care in working on or around vehicles, batteries or electrical devices.

Transportation expenses for warranty services are also excluded from this warranty.

VOIDING OF WARRANTY

This and any other warranty shall be void if the vehicle or component is abused or used in an unintended manner or shows indications that it has been altered in any way, including, but not limited to, modification of the speed governor, braking system, steering, transaxle, or other operating systems of the car to cause it to perform outside club car specifications. The warranty is likewise void if the vehicle shows indications that reasonable or necessary maintenance as outlined in the owner's manual and maintenance and service manual was not performed at the time and in the manner specified in such manuals.

SOLE REMEDY

Club Car's liability under this limited warranty or in any action whether based upon warranty, contract, negligence, strict product liability or otherwise, shall be the repair or replacement, at Club Car's option, of the vehicle or component thereof that Club Car deems to be defective. Replacement shall mean furnishing, during the applicable limited warranty period, a new vehicle or factory-reconditioned vehicle or component thereof that is identical or reasonably equivalent to the warranted product or component at no cost to the purchaser. Repair shall mean remedying a defect in the vehicle or component thereof at no cost to the purchaser during the applicable limited warranty period. Club Car reserves the right to test and recharge any component returned for adjustment. If Club Car elects to repair the vehicle or component, it may provide factory-reconditioned parts or components. All parts and components replaced under warranty shall become the property of Club Car.

DISCLAIMER

This limited warranty is exclusive. Club Car makes no other warranty of any kind, expressed or implied. Any implied warranties of merchantability or fitness for a particular purpose are hereby disclaimed by Club Car and excluded from this warranty. The Purchaser and Club Car expressly agree that the sole remedy of the replacement or repair of the defective vehicle or component thereof is the sole remedy of the Purchaser. Club Car makes no other representation or warranty of any kind, and no representative, employee, distributor or dealer of Club Car has the authority to make or imply any representation, promise or agreement, which in any way varies the terms of this warranty.

In the event that another pre-printed warranty document, certificate or both offered by or through Club Car at the time of sale of this vehicle (each an "Additional Warranty Document") is deemed to conflict with the limitations or exclusions contained herein, the limitations and exclusions contained herein shall continue to apply to both this limited warranty statement and, to the maximum extent permitted by law, to each Additional Warranty Document.

NO CONSEQUENTIAL DAMAGES

In no event shall Club Car be liable for any incidental or consequential damages including, but not limited to, loss related to property other than the vehicle, loss of use, loss of time, inconvenience, or any other economic loss.





Some states allow neither limitation on the duration of an implied warranty nor exclusions or limitation of incidental or consequential damages. Therefore, the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

HOW TO MAKE A WARRANTY CLAIM

To make a warranty claim under this limited warranty, you must present the vehicle or defective component with evidence of proof of purchase date and number of amp hours (if applicable) to an authorized Club Car dealer.

For warranty-related communication, contact:

<u>E-mail</u>

cci_warrantyadministration@clubcar.com

Postal Service

Club Car, LLC Attention: Warranty Services 4125 Washington Rd. Evans, Georgia 30809 Unites States Of America



(Page intentionally left blank.)

(Page intentionally left blank.)

Publication Part Number TPCC01MF00EN019

Edition Code A



Club Car, LLC P.O. Box 204658 Augusta, GA 30917-4658 USA
 Web
 www.clubcar.com

 Phone
 1 706 258 2225

 1 800 ClubCar

 Fax
 1 706 863 5858